


**Model Nos. 2324, 2345, 2351,
2366, 2373, 84904**
PILE DRIVER III PUMP ASSEMBLY
Series "B"

**PILEDRIVER III
PUMP ASSEMBLY**



84803, 84804, 94804, 94806, 94808
84806, 84808 AIR MOTORS with AIRBRAKE®
Refer to Section A50 Page 78 Series. Refer to Section A50 Page 84 Series.

WARNING

KEEP HANDS AWAY FROM PUMP INLET WHILE AIRLINE IS CONNECTED. DO NOT OPERATE PUMP UNLESS IT IS FIRMLY MOUNTED ONTO PRESSURE PRIMER OR STANDPIPE AND AREA AROUND PUMP INLET IS CLEAR OF OBSTRUCTIONS.

WARNING

DO NOT OPERATE WITH COMBUSTIBLE GAS

© Indicates Change

SPECIFICATIONS

Model	Ratio	Airmotor Size in. (mm)	Airmotor Model	Maximum Discharge Pressure PSIG (Bar)	Output Per Cycle cu. in. (cc)	Stroke Length in. (mm)	Minimum Air Supply Hose in. (mm)	Maximum Operating Air Pressure PSIG (Bar)	Operating Temperature F° (C°)
2345	45:1	10 (254)	84810	4,500 (311)	18 (295)	6 (152)	3/4 (20)	100 (7)	30° to 200° (-34° to +93°)
2324	30:1	8 (203)	84808	3,000 (207)					
2351	18:1	6 (152)	84806	1,800 (124)					
2366	8:1	4-1/4 (108)	84804	1,600 (110)					
2373	4:1	3 (76)	84803	300 (21)					
							1/2 (12)	200 (14)	
							3/8 (10)		

NOTE: Pump should be installed upright for operation. Use Model 83727 stand pipe for bulk material dispensing. Locate pump as close to tank as possible and use a minimum 3 inch (76mm) I.D. inlet hose or pipe.

ATTACHING AIRMOTOR TO PUMPTUBE*

1. Tightly attach tie rods to the airmotor (use short threaded end of the tie rods).
2. Mount airmotor on top of the pump-tube outlet and tightly connect Coupling Nut (237051) to airmotor piston rod.
3. Hand tighten tie rods to the outlet with four nuts supplied with airmotor.
4. Slowly cycle the pump several times, using just enough air pressure to operate the pump without stalling.
5. Stop the pump on an "up" stroke and tighten the four nuts to securely fasten the airmotor to the pumptube.

OPERATING PRECAUTIONS

- Use Lincoln replacement parts to assure compatible pressure rating.
- HEED ALL WARNINGS.
- Be sure material hoses and other components are able to withstand fluid pressures developed by this pump.
- Do not operate pump continuously at speeds in excess of 75 cycles per minute.
- Disconnect air line from pump air motor when system sits idle for long periods of time.
- **SERVICING.** Before servicing or cleaning pump, or removing fluid hose or gun from a unit that has been used, be sure to disconnect air lines and carefully bleed pressure off of the system.

- Check continuity (a good static wire connection) with an ohmmeter. Place one probe on one hose fitting and the other probe on other hose fitting, continuity or proper grounding through hose is good when a reading is obtained on the ohmmeter.
- **PREVENT FIRES.** When pumping, flushing or recirculating volatile solvents, the area must be adequately ventilated.
- Keep solvents away from heat, sparks and open flames. Keep containers closed when not in use.



GLAND PACKING DESIGN*

Many industrial type materials (sealants, adhesives, inks, etc.) display a tendency to dry-out and to build-up on the pump rod (plunger). These hard dried out materials cause the gland packing to wear out rapidly, resulting in leakage and ultimate pump failure. The second problem is the gland seal exposure to high pressure and in particular, to pressure fluctuation during pump operation (stroke changeover).

The new gland packing design* of Pile Driver III pumps addresses both problems:

A special spring type Metal Wiper (237654), scrapes built up and dried out material from the pump rod (plunger). In order to help the metal wiper to work longer and more efficiently, the lube well of the pump should be filled with a fluid compatible with pumped material.

Do not fill lube well to full capacity, as the reciprocating movement of the pump may draw fluid into the airmotor.

* U.S. Patent No. 4,976,192

Secondly a special Protection Sleeve (237648) with concentric grooves creates a labyrinth path and reduces internal operational pressure and at the same time pressure fluctuation during a stroke changeover, limits gland seal exposure to pumped material.

A combination of the metal scraper and protection sleeve prolongs gland seal life and prevents leakage.

PUMP PRIMING

To start operating, the pump has to be primed with pumped material. The Pile Driver III pump is double acting (pumps material on "up" & "down" stroke) positive displacement reciprocating pump and as such intakes material only on "up" stroke.


To prime pump-open output line (material valve) and slowly open air supply valve until pump starts. Allow pump to cycle very slowly until all air is pushed out of lines and material fills out pump and lines. Close output line (material valve) - pump should stall against pressure.

If pump fails to prime properly open Bleeder Valve (84012) slightly to expel trapped air and at the sign of material coming out of the valve close it tightly.


Note: Pumps are factory tested with light oil and some of it is left in, to protect pump parts during storage and transportation. To prevent contamination of material to be pumped, flush pump before using.

OUTLET POSITION ADJUSTMENT

The position of the pump outlet may be adjusted by loosening the three set screws (246836) and rotating the pumptube outlet into the position desired. Retighten the set screws to 12 ft/lbs.



**PILEDRIVERIII
PUMP ASSEMBLY
84904**




NOTE:
Install scraper ring
with sharp edge up,
as shown.

PUMPTUBESERVICE KITS

	Polyurethane	Teflon	Polyethylene
Seal Kit	84909	84916	84917
Gland Seal Kit	85314	85324	85330

Polyurethane Seal Kit contains all soft seals.
Teflon and Polyethylene Seal Kits contain gland and piston u-cups only.
Gland Seal kits contain gland u-cup and o-ring only.



© Indicates Change

SERVICEPARTS

PART	QTY.	DESCRIPTION	PART	QTY.	DESCRIPTION	PART	QTY.	DESCRIPTION
13252	1	Connector (1-1/8" hex)	236257	1	Pump Tube	237654	1	Wiper
68649	1	Check Ball	236266	1	Outlet Body	237659	1	Gland Nut (2-5/8" hex)
84012	1	Bleeder valve (3/4" flats)	237051	1	Coupling nut (1-1/8" hex)	246836	3	Set screw (3/16" hex socket)
93075	1	Priming plug	237121	1	Check	*246837	1	O-ring (nitrile)
236225	1	Bolt connector (7/8" hex)	237123	1	Plunger (1-1/8" flats)	246906	1	Piston Nut (1-5/8" flats)
236228	1	Check Seat	**237125	1	U-cup (polyurethane)	246907	1	Piston Body (1-1/8" flats)
*236236	2	U-cup (polyurethane)	237127	1	Bushing	246908	1	Piston Collar
*236237	3	O-ring (polyurethane)	237648	1	Sleeve	246917	1	Inlet Bushing (3-1/2" flats)
#* 236238	1	O-ring (polyurethane)	237653	1	Spacer	246920	1	Mounting flange

* Included in 84909 Seal Kit

Included in 85314 Gland Seal Kit

TROUBLESHOOTING

Problem	Possible Cause	Solution
Pump does not operate.	Restricted or inadequate air supply.	Check air supply pressure and air hose (see specifications for minimum air supply diameter).
Erratic or accelerated operation.	Obstructed material output.	Check output line for restrictions.
	Pump is not primed.	Prime pump (see "pump priming instructions").
	Insufficient material supply.	Refill material supply.
Pump operates on "down" stroke only (missing "up" stroke).	Material is too heavy for priming.	Lower output with material valve. Increase pressure to pressure primer (if in use) to overcome inlet restrictions.
	Worn or damaged piston packing (236236) or piston check (68649 & 246907).	Check and replace if needed.
Pump operates on "up" stroke only (missing "down" stroke).	Worn or damaged inlet check (237121).	Check and replace if needed.
	Insufficient material supply, pump not intaking enough material to displace material both strokes.	Check inlet for restrictions. lower output with material valve.
Pump is operating but not displacing material.	Inlet check (237121) is not seated or damaged.	Check and replace if needed.

DISASSEMBLY PROCEDURE

Tools Required	(Used on Part #)	Tools Required	(Used on Part #)
3/16" hex key	(246836)	1-5/8" wrench	(246906)
3/4" wrench	(84012)	2-5/8" wrench	(237659)
7/8" wrench	(236225)	3-1/2" wrench	(246917)
1-1/8" wrench	(13252, 237051, 237123 & 246907)	3" dia. strap wrench	(236257)
		Two screwdrivers	(237127)

Procedure

1. Remove Set Screws 246836 from Mounting Flange 246920.
2. Remove Mounting Flange 246920 from Inlet Bushing 246917.
 - a. Remove priming Plug 93075 from Connector 13252.
 - b. Remove Connector 13252 from Mounting Flange 246920.
3. Remove Inlet Bushing 246917 from pump Tube 236257.
 - a. Remove O-ring 246837 from Inlet Bushing 246917.
 - b. Remove Check Seat 246228 from Inlet Bushing 246917.
 - c. Remove O-ring 236237 from Check Seat 236228.
4. Remove Check 237121 from Pump Tube 236257.
5. Remove Bolt Connector 236225 from Plunger 237123.
6. Remove piston and plunger assembly from bottom of Pump Tube 236257.
 - a. Remove piston assembly from plunger 237123.
 - b. Remove Piston Nut 246906 and Check Ball 68649 from Piston Body 246907.
 - c. Remove U-cup 236236 from Piston Nut 246906.
 - d. Remove Piston Collar 246908 from Outlet Body 236266.
7. Remove Pump Tube 236257 from Outlet Body 236266.
 - a. Remove O-rings 236237 from Pump Tube 236257.
8. Remove Bleeder Valve 84012 from Outlet Body 236266.
9. Remove Gland Nut 237659 from Outlet Body 236266.
 - a. Remove Wiper 237654 and Spacer 237653 from Gland Nut 237659.
10. Remove Bushing 237127 from Outlet Body 236266.
 - a. Remove O-ring 236238 and U-cup 237125 from Bushing 237127.
11. Remove Sleeve 27648 from Outlet Body 236266.
12. To reassemble pump, reverse disassembly procedure. (Refer to illustration for torque specifications.)

RETAIN THIS INFORMATION FOR FUTURE REFERENCE

When ordering replacement parts, list: Part Number, Description, Model Number and Series Letter.

LINCOLN provides a Distributor Network that stocks equipment and replacement parts.