

# SERVICE & OPERATING MANUAL



## Models 85631, 85632, 85633 1/2" Aluminum Air-Powered Diaphragm Pump



CE

U.S. Patent #  
400,210; 5,996,627  
6,241,487

### Table of Contents

Engineering Data and Temperature Limitations .....	1	Available Service and Conversion Kits .....	10
Performance Curve .....	2	Composite Repair Parts List .....	11
Dimensions .....	3	Air Distribution Valve Assembly Drawing and Parts List .....	12
Metric Dimensions .....	4	Air Distribution Valve Servicing .....	13
Principle of Pump Operation .....	5	Pilot Valve Assembly Drawing and Parts List .....	14
Installation and Start-up .....	5	Pilot Valve Servicing .....	15
Air Supply .....	5	Intermediate Assembly Drawing and Parts List .....	16
Air Valve Lubrication .....	5	Intermediate Assembly Servicing .....	16
Air Line Moisture .....	5	Diaphragm Service Drawing .....	18
Air Inlet and Priming .....	5	Diaphragm Service Drawing, with Overlay .....	18
Between Uses .....	5	Diaphragm Servicing .....	19
Installation Guide .....	6	Overlay Diaphragm Servicing .....	19
Troubleshooting .....	7	Check Valve Servicing .....	20
Warranty .....	7	Check Valve Drawing .....	20
Recycling .....	8	Pumping Hazardous Liquids .....	21
Important Safety Information .....	8	Converting the pump for piping the exhaust air .....	21
Composite Repair Parts Drawing .....	10	Exhaust Conversion Drawing .....	21
		Converted Exhaust Illustration .....	21

Section - B5  
Page - 29A







# Models 85631, 85632, 85633

## 1/2" Aluminum Air-Powered Double-Diaphragm Pump

ENGINEERING, PERFORMANCE  
& CONSTRUCTION DATA



Air Exhaust Side View



Air Inlet Side View




U.S. Patent #  
5,996,627 & 6,241,487  
Other U.S. Patents  
Applied for

<b>INTAKE/DISCHARGE PIPE SIZE</b> 1/2" NPT 1" NPT	<b>CAPACITY</b> 0 to 15 gallons per minute (0 to 56 liters per minute)	<b>AIR VALVE</b> No-lube, no-stall design	<b>SOLIDS-HANDLING</b> Up to .125 in. (3mm)	<b>HEADS UP TO</b> 125 psi or 289 ft. of water (8.6 Kg/cm <sup>2</sup> or 86 meters)	<b>DISPLACEMENT/STROKE</b> .026 Gallon / .098 liter
---	--	---	--	--	--

**CAUTION!** Operating temperature limitations are as follows:

Materials	Operating Temperatures		
	Maximum*	Minimum*	Optimum**
<b>Buna</b> General purpose, oil-resistant. Shows good solvent, oil, water and hydraulic fluid resistance. Should not be used with highly polar solvents like acetone and MEK, ozone, chlorinated hydrocarbons and nitro hydrocarbons.	190°F 88°C	-10°F -23°C	50° to 140°F 10° to 60°C
<b>Santoprene®</b> Injection molded thermoplastic elastomer with no fabric layer. Long mechanical flex life. Excellent abrasion resistance.	212°F 100°C	-10°F -23°C	50° to 212°F 10° to 100°C
<b>Virgin PTFE</b> Chemically inert, virtually impervious. Very few chemicals are known to react chemically with PTFE: molten alkali metals, turbulent liquid or gases fluorine and a few fluoro-chemicals such as chlorine trifluoride or oxygen difluoride which readily liberate free fluorine at elevated temperatures.	212°F 100°C	-35°F -37°C	50° to 212°F 10° to 100°C
<b>Polypropylene</b>	150°F 65°C	-40°F -40°C	
<b>Polyethylene</b>	180°F 82°C	-40°F -40°C	50°F to 140°F 10°C to 60°C
<b>Hytrel®</b>	190°F 88°C	-10°F -23°C	50°F to 140°F 10°C to 60°C


# Performance Curve, Models 85631, 85632, 85633



# Dimensions: with Integral Muffler


Dimensions in Inches

Dimensional tolerance:  $\pm 1/8"$




FRONT VIEW

STANDARD  
ENCAPSULATED MUFFLER:  
3/8" NPT EXHAUST PORT  
FOR OPTIONAL PIPING MUFFLER  
STYLES OR PIPING EXHAUST  
AIR IN SUBMERGED  
APPLICATIONS.



BOTTOM VIEW




SIDE VIEW

DIMENSION	A	B
Standard Pump	4 1/16"	7 1/16"
Mesh Muffler	5 3/4"	8 3/4"


# Metric Dimensions: with Integral Muffler

Dimensions in millimeters  
Dimensional tolerance:  $\pm 3\text{mm}$




FRONT VIEW

STANDARD ENCAPSULATED MUFFLER:  
3/8" NPT EXHAUST PORT  
FOR OPTIONAL PIPING MUFFLER  
STYLES OR PIPING EXHAUST  
AIR IN SUBMERGED  
APPLICATIONS.



BOTTOM VIEW



SIDE VIEW

DIMENSION	A	B
Standard Pump	103mm	179mm
Mesh Muffler	146mm	222mm

## PRINCIPLE OF PUMP OPERATION

This ball type check valve pump is powered by compressed air and is a 1:1 ratio design. The inner side of one diaphragm chamber is alternately pressurized while simultaneously exhausting the other inner chamber. This causes the diaphragms, which are connected by a common rod secured by plates to the centers of the diaphragms, to move in a reciprocating action. (As one diaphragm performs the discharge stroke the other diaphragm is pulled to perform the suction stroke in the opposite chamber.) Air pressure is applied over the entire inner surface of the diaphragm while liquid is discharged from the opposite side of the diaphragm. The diaphragm operates in a balanced condition during the discharge stroke which allows the pump to be operated at discharge heads over 200 feet (61 meters) of water.

For maximum diaphragm life, keep the pump as close to the liquid being pumped as possible. Positive suction head in excess of 10 feet of liquid (3.048 meters) may require a back pressure regulating device to maximize diaphragm life.

Alternate pressurizing and exhausting of the diaphragm chamber is performed by an externally mounted, pilot operated, four way spool type air distribution valve. When the spool shifts to one end of the valve body, inlet pressure is applied to one diaphragm chamber and the other diaphragm chamber exhausts. When the spool

shifts to the opposite end of the valve body, the pressure to the chambers is reversed. The air distribution valve spool is moved by an internal pilot valve which alternately pressurizes one end of the air distribution valve spool while exhausting the other end. The pilot valve is shifted at each end of the diaphragm stroke when an actuator plunger is contacted by the diaphragm plate. This actuator plunger then pushes the end of the pilot valve spool into position to activate the air distribution valve.

The chambers are connected with manifolds with a suction and discharge check valve for each chamber, maintaining flow in one direction through the pump.

## INSTALLATION AND START-UP

Locate the pump as close to the product being pumped as possible. Keep the suction line length and number of fittings to a minimum. Do not reduce the suction line diameter.

For installations of rigid piping, short sections of flexible hose should be installed between the pump and the piping. The flexible hose reduces vibration and strain to the pumping system. A surge dampener is recommended to further reduce pulsation in flow.

## AIR SUPPLY

Air supply pressure cannot exceed 100 psi (7 bar). Connect the pump air inlet to an air supply of sufficient capacity and pressure required for desired performance. When the air supply line

is solid piping, use a short length of flexible hose not less than ½" (13mm) in diameter between the pump and the piping to reduce strain to the piping. The weight of the air supply line, regulators and filters must be supported by some means other than the air inlet cap. Failure to provide support for the piping may result in damage to the pump. A pressure regulating valve should be installed to insure air supply pressure does not exceed recommended limits.

## AIR VALVE LUBRICATION

The air distribution valve and the pilot valve are designed to operate WITHOUT lubrication. This is the preferred mode of operation. There may be instances of personal preference or poor quality air supplies when lubrication of the compressed air supply is required. The pump air system will operate with properly lubricated compressed air supply. Proper lubrication requires the use of an air line lubricator set to deliver one drop of SAE 10 non-detergent oil for every 20 SCFM (9.4 liters/sec.) of air the pump consumes at the point of operation. Consult the pump's published Performance Curve to determine this.

## AIR LINE MOISTURE

Water in the compressed air supply can create problems such as icing or freezing of the exhaust air, causing the pump to cycle erratically or stop operating. Water in the air supply can be reduced by using a point-of-use air dryer to supplement the user's air drying equipment. This device removes water

from the compressed air supply and alleviates the icing or freezing problems.

## AIR INLET AND PRIMING

To start the pump, open the air valve approximately ½ to ¾ turn. After the pump primes, the air valve can be opened to increase air flow as desired. If opening the valve increases cycling rate, but does not increase the rate of flow, cavitation has occurred. The valve should be closed slightly to obtain the most efficient air flow to pump flow ratio.



## BETWEEN USES

When the pump is used for materials that tend to settle out or solidify when not in motion, the pump should be flushed after each use to prevent damage. (Product remaining in the pump between uses could dry out or settle out. This could cause problems with the diaphragms and check valves at restart.) In freezing temperatures the pump must be completely drained between uses in all cases.

# INSTALLATION GUIDE

## Top Discharge Ball Valve Unit

- ① Surge Suppressor
- ② Filter/Regulator
- ③ Lubricator



**Possible Symptoms:**

- Pump will not cycle.
- Pump cycles, but produces no flow.
- Pump cycles, but flow rate is unsatisfactory.
- Pump cycle seems unbalanced.
- Pump cycle seems to produce excessive vibration.

**What to Check:** Excessive suction lift in system.

**Corrective Action:** For lifts exceeding 20 feet (6 meters), filling the pumping chambers with liquid will prime the pump in most cases.

**What to Check:** Excessive flooded suction in system.

**Corrective Action:** For flooded conditions exceeding 10 feet (3 meters) of liquid, install a back pressure device.

**What to Check:** System head exceeds air supply pressure.

**Corrective Action:** Increase the inlet air pressure to the pump. Most diaphragm pumps are designed for 1:1 pressure ratio at zero flow.

**What to Check:** Air supply pressure or volume exceeds system head.

**Corrective Action:** Decrease inlet air pressure and volume to the pump as calculated on the published PERFORMANCE CURVE. Pump is cavitating the fluid by fast cycling.

**What to Check:** Undersized suction line.

**Corrective Action:** Meet or exceed

pump connection recommendations shown on the DIMENSIONAL DRAWING.

**What to Check:** Restricted or undersized air line.

**Corrective Action:** Install a larger air line and connection. Refer to air inlet recommendations shown in your pump's SERVICE MANUAL.

**What to Check:** Check ESADS, the Externally Serviceable Air Distribution System of the pump.

**Corrective Action:** Disassemble and inspect the main air distribution valve, pilot valve and pilot valve actuators. Refer to the parts drawing and air valve section of the SERVICE MANUAL. Check for clogged discharge or closed valve before reassembly.

**What to Check:** Rigid pipe connections to pump.

**Corrective Action:** Install flexible connectors and a surge dampener.

**What to Check:** Blocked air exhaust muffler.

**Corrective Action:** Remove muffler screen, clean or de-ice and reinstall. Refer to the Air Exhaust section of your pump SERVICE MANUAL.

**What to Check:** Pumped fluid in air exhaust muffler.

**Corrective Action:** Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly. Refer to the Diaphragm Replacement section of your pump SERVICE MANUAL.

**What to Check:** Suction side air leakage or air in product.

**Corrective Action:** Visually inspect all suction side gaskets and pipe connections.

**What to Check:** Obstructed check valve.

**Corrective Action:** Disassemble the wet end of the pump and manually dislodge obstruction in the check valve pocket. Refer to the Check Valve section of the pump SERVICE MANUAL for disassembly instructions.

**What to Check:** Worn or misaligned check valve or check valve seat.

**Corrective Action:** Inspect check valves and seats for wear and proper seating. Replace if necessary. Refer to Check Valve section of the pump SERVICE MANUAL for disassembly instructions.

**What to Check:** Blocked suction line.

**Corrective Action:** Remove or flush obstruction. Check and clear all suction screens and strainers.

**What to Check:** Blocked discharge line.

**Corrective Action:** Check for obstruction or closed discharge line valves.

**What to Check:** Blocked pumping chamber.

**Corrective Action:** Disassemble and inspect the wetted chambers of the pump. Remove or flush any obstructions. Refer to the pump SERVICE MANUAL for disassembly instructions.

**What to Check:** Entrained air or vapor lock in one or both pumping chambers.

**Corrective Action:** Purge chambers through tapped chamber vent plugs. PURGING THE CHAMBERS OF AIR CAN BE DANGEROUS! Contact Customer Service before performing this procedure. A model with top-ported discharge will reduce or eliminate problems with entrained air.

If your pump continues to perform below your expectations, contact the Customer Service Department for a service evaluation.

This pump is warranted for a period of five years against defective material and workmanship.

# RECYCLING

Many components of LINCOLN AODD pumps are made of recyclable materials. We encourage pump users to recycle worn out parts and pumps whenever possible, after any hazardous pumped fluids are thoroughly flushed.

## IMPORTANT SAFETY INFORMATION



### ! IMPORTANT

Read these safety warnings and instructions in this manual completely, before installation and start-up of the pump. It is the responsibility of the purchaser to retain this manual for reference. Failure to comply with the recommendations stated in this manual will damage the pump, and void factory warranty.



### ! CAUTION

Before pump operation, inspect all gasketed fasteners for looseness caused by gasket creep. Retorque loose fasteners to prevent leakage. Follow recommended torques stated in this manual.



### ! WARNING

Before maintenance or repair, shut off the compressed air line, bleed the pressure, and disconnect the air line from the pump. The discharge line may be pressurized and must be bled of its pressure.



### ! WARNING

In the event of diaphragm rupture, pumped material may enter the air end of the pump, and be discharged into the atmosphere. If pumping a product which is hazardous or toxic, the air exhaust must be piped to an appropriate area for safe disposition.



### ! WARNING

Take action to prevent static sparking. Fire or explosion can result, especially when handling flammable liquids. The pump, piping, valves, containers or other miscellaneous equipment must be grounded.



### ! WARNING

This pump is pressurized internally with air pressure during operation. Always make certain that all bolting is in good condition and that all of the correct bolting is reinstalled during assembly.



### ! WARNING

When used for toxic or aggressive fluids, the pump should always be flushed clean prior to disassembly.



### ! WARNING

Before doing any maintenance on the pump, be certain all pressure is completely vented from the pump, suction, discharge, piping, and all other openings and connections. Be certain the air supply is locked out or made non-operational, so that it cannot be started while work is being done on the pump. Be certain that approved eye protection and protective clothing are worn all times in the vicinity of the pump. Failure to follow these recommendations may result in serious injury or death.



### ! WARNING

Airborne particles and loud noise hazards. Wear ear and eye protection.




# Composite Repair Parts Drawing

## Available Service and Conversion Kits

### PART NO. DESCRIPTION

<b>252891</b>	<b>AIR END KIT</b> Seals, O-rings, Gaskets, Retaining Rings, Air Valve, Sleeve & Spool, Spool and Pilot Valve Assembly.
<b>271856</b>	<b>WETTED END KIT</b> Hytrell Diaphragm, Hytrell Check Balls, UHMW Seats, Buna Spacer Gasket. (For Model 85633)
<b>271854</b>	<b>WETTED END KIT</b> Buna Diaphragm, Buna Check Balls, UHMW Seats. (For Model 85631)
<b>271855</b>	<b>WETTED END KIT</b> Santoprene Diaphragm, PTFE Overlay Diaphragm, PTFE Check Balls, PTFE Seats. (For Model 85632)




Overlay Option

# Composite Repair Parts List

ITEM	DESCRIPTION	QTY	MODEL 85631	MODEL 85632	MODEL 85633
1	Air Valve Assembly	1	252894	252894	252894
2	Ball, Check	4	272208	252896	272209
3	Pilot Valve Assembly	1	252897	252897	252897
4	Bracket, Intermediate	1	271986	271986	271986
5	Bracket, Mounting	2	271857	271857	271857
6	Bumper, Diaphragm	2	252900	252900	252900
7	Bushing, Plunger	2	252901	252901	252901
8	Cap, Air Inlet	1	271987	271987	271987
9	Capscrew, Socket Head 1/4-20 x .50	4	271858	271858	271858
10	Capscrew, Flanged 5/16-18 x 1.00	12	271859	271859	271859
11	Capscrew, Flanged 5/16-18 x 1.25	24	271860	271860	271860
12	Capscrew, Flanged 5/16-18 x 1.50	12	271861	271861	271861
13	Capscrew, Flanged 1/4-20 x 1.25	8	271862	271862	271862
14	Chamber, Outer	2	271864	271864	271864
15	Diaphragm	2	271865	252907	272213
16	Diaphragm, Overlay	2		252908	
17	Elbow, Suction	2	271866	271866	271866
18	Elbow, Discharge	2	271867	271867	271867
19	Gasket, Spacer	2	252910		252910
20	Gasket, Air Inlet	1	252911	252911	252911
21	Gasket, Pilot Valve	1	252912	252912	252912
22	Gasket, Air Valve	1	252913	252913	252913
23	Manifold	2	271868	271868	271868
24	Nut, Hex Flange 5/16-18"	36	271993	271993	271993
25	O-Ring	2	240655	240655	240655
26	O-Ring, Manifold	4	244191		
27	Seal, Manifold	4		272214	272214
28	Plate, Outer Diaphragm	2	240673	240673	240673
29	Plate, Inner Diaphragm	2	252917	252917	252917
30	Plunger, Actuator	2	252918	252918	252918
31	Ring, Retaining	2	240717	240717	240717
32	Rod, Diaphragm	1	252920	252920	252920
33	Seal, Diaphragm Rod	2	252921	252921	252921
34	Seat, Check Valve	4	271870	271870	271870

# Air Distribution Valve Assembly Drawing



## MAIN AIR VALVE ASSEMBLY PARTS LIST

ITEM	PART NUMBER	DESCRIPTION	QTY
1	252894	Main Air Valve Assembly	1
1-A	252925	Body, Air Valve	1
1-B	252926	Cap, End with o-ring	2
1-C	252927	O-Ring	8
1-D	252928	Ring, Retaining	2
1-E	252929	Sleeve and Spool Set w/o-rings	1
1-F	252930	Muffer	1
1-G	252931	Cap, Muffer	1
1-H	252932	Screws, Self-Tapping	4

## AIR DISTRIBUTION VALVE SERVICING

To service the air valve first shut off the compressed air, bleed pressure from the pump, and disconnect the air supply line from the pump.

### **STEP #1:** See COMPOSITE REPAIR PARTS DRAWING.

Using a  $\frac{7}{16}$ " Allen wrench or socket, remove the four capscrews (item 13). Remove the air valve assembly from the pump.

Remove and inspect gasket (item 22) for cracks or damage. Replace gasket if needed.

### **STEP #2:** Disassembly of the air valve.

To access the internal air valve components first remove the two retaining rings (item 1-D) from each end of the air valve assembly using clip ring pliers.

Next remove the two end caps (item 1-B). Inspect the o-ring (item 1-C) for cuts or wear. Replace the o-rings if necessary.

Remove the spool (part of item 1-E) from the sleeve. Be careful not to scratch or damage the outer diameter of the spool. Wipe spool with a soft cloth and inspect for scratches or wear.

Inspect the inner diameter of the sleeve (part of item 1-E) for dirt, scratches, or other contaminants. Remove the sleeve if needed and replace with a new sleeve and spool set (item 1-E).

### **STEP #3:** Reassembly of the air valve.

Install one end cap (item 1-B) with an o-ring (item 1-C) into one end of the air valve body (item 1-A). Install one retaining ring (item 1-D) into the groove on the same end.

Remove the new sleeve and spool set (item 1-E) from the plastic bag. Carefully remove the spool from the sleeve. Install the six o-rings (item 1-C) into the six grooves on the sleeve. Apply a light coating of grease to the o-rings before installing the sleeve into the valve body (item 1-A). align the slots in the sleeve with the slots in the valve body. Insert the spool into the sleeve. Be careful not to scratch or damage the spool during installation. Push the spool in until touches the end cap on the opposite end.

Install the remaining end cap with o-ring and retaining ring.

Fasten the air valve assembly (item 1) and gasket (item 22) to the pump.


Connect the compressed air line to the pump. The pump is now ready for operation.



## **! IMPORTANT**

*Read these instructions completely, before installation and start-up. It is the responsibility of the purchaser to retain this manual for reference. Failure to comply with the recommendations stated in this manual will damage the pump, and void factory warranty.*

# Pilot Valve Assembly Drawing



## PILOT VALVE ASSEMBLY PARTS LIST

ITEM	PART NUMBER	DESCRIPTION	QTY
3	252897	Pilot Valve Assembly	
3-A	252933	Body, Pilot Valve	1
3-B	252934	Bushing, Pilot Valve	2
3-C	252935	Ring, Spiral Retaining	2
3-D	252936	Spacer	5
3-E	252937	Spool, Pilot Valve	1
3-F	252938	Wiper	6

## PILOT VALVE SERVICING

To service the pilot valve first shut off the compressed air supply, bleed the pressure from the pump, and disconnect the air supply line from the pump. Insert the safety clip (item 1-G from Air Distribution Valve assembly drawing) into the smaller unthreaded holes in the end cap (item 1-F from air distribution valve assembly drawing).

### Step #1: See PUMP ASSEMBLY DRAWING.

Using a  $\frac{7}{16}$ " wrench or socket, remove the four capscrews (items 13). Remove the air inlet cap (item 8) and air inlet gasket (item 20). The pilot valve assembly (item 3) can now be removed for inspection or service.

### Step #2: Disassembly of the pilot valve.

Remove the pilot valve spool (item 3-E). Wipe clean, and inspect for dirt, scratches or wear. Replace the spool if necessary.

Remove the two spiral retaining rings (items 3-C) from each end of the pilot valve body by inserting the tip of a small flat screw driver under the notch in the retaining ring. Lift and push the ring clockwise in a circular motion.

Remove the two pilot valve bushings (items 3-B), five spacers (items 3-D), and six spool wipers (items 3-F) by pushing gently from other end of the pilot valve body. Inspect the wipers and spacers for cuts and/or wear. Replace wipers and/or spacers as necessary.

### Step #3: Re-assembly of the pilot valve.

First install a spiral retaining ring to one end of the pilot valve body. Spread the spiral and insert one end into the groove in the pilot valve body. Twist the ring in a clockwise motion until the full ring is snapped into the groove. Install one bushing making sure the step side faces toward the wiper. Apply a light coating of grease to the outside diameter of each wiper. Next, gently push in the wipers and spacers until they are against the installed retaining ring in the opposite end of the pilot valve body. Install the remaining bushing making sure the step side faces the wiper. Install the remaining spiral retaining ring using the same method described.

Apply a light coating of grease to the inner diameter of each wiper. Also apply a light coating of grease to the outer diameter of the pilot valve spool and gently push the spool through each wiper.

### Step #4: Inspect the actuator plungers.

See PUMP ASSEMBLY DRAWING.

The actuator plungers (items 30) can be reached through the stem cavity of the pilot valve in the intermediate bracket (item 4). To service bushings, o-rings and retaining rings, see Intermediate Drawing.

Remove the plungers (items 30) from the bushings (item 7) in each end of the intermediate cavity. Apply a light coating of grease to each o-ring and re-install the plungers in to the bushings. Push the plungers in as far as they will go.

### Step #5: Re-install the pilot valve assembly into the intermediate assembly.

Be careful to align the ends of the stem between the plungers when inserting the stem of the pilot valve into the cavity of the intermediate.

Re-install the gasket (item 20), air inlet cap (item 8) and capscrews (items 13).


Connect the air supply to the pump. Remove the safety clip (item 1-G) from the end cap (item 1-F). The pump is now ready for operation.



**! IMPORTANT**

*Read these instructions completely, before installation and start-up. It is the responsibility of the purchaser to retain this manual for reference. Failure to comply with the recommendations stated in this manual will damage the pump, and void factory warranty.*

## Intermediate Assembly Drawing



### INTERMEDIATE REPAIR PARTS LIST

ITEM	PART NUMBER	DESCRIPTION	QTY
4	271986	Bracket, Intermediate	1
7	252901	Bushing, Plunger	2
25	240655	O-Ring	2
31	240717	Ring, Retaining*	2

**\*NOTE:** It is recommended that when plunger components are serviced, new retaining rings be installed.

## Intermediate Assembly Servicing

### PLUNGER BUSHING, O-RING, AND RETAINING RING SERVICING

To service the plunger bushing components first remove the two retaining rings (items 31) using a small flat screwdriver. **\*Note:** It is recommended that new retaining rings be installed.

Next remove the two plunger bushings (items 7). Inspect the bushings for wear or scratches. Replace the bushings as necessary.

Inspect the two o-rings (25) for cuts and/or wear.




**! IMPORTANT**

*Read these instructions completely, before installation and start-up. It is the responsibility of the purchaser to retain this manual for reference. Failure to comply with the recommendations stated in this manual will damage the pump, and void factory warranty.*




# Diaphragm Service Drawing



**Diaphragm Orientation**  
Install diaphragm and spacer as shown above.

# Diaphragm Service Drawing, with Overlay



**Diaphragm Orientation**  
Install diaphragm and overlay as shown above.

## DIAPHRAGM SERVICING

To service the diaphragm first shut off the suction, then shut off the discharge lines to the pump. Shut off the compressed air supply, bleed the pressure from the pump, and disconnect the air supply line from the pump. Drain any remaining liquid from the pump.

**Step #1:** See the pump composite repair parts drawing, and the diaphragm servicing illustration.

Using a 1/2" wrench or socket, remove 8 capscrews (items 10 and 11), and nuts that fasten the discharge elbows (item 18). Remove the elbows and manifold (items 18 and 23). Use the same procedure to remove the suction elbows and manifold assembly (items 17 and 23).

**Step #2:** Removing the outer chambers. Using a 1/2" wrench or socket, remove the 16 capscrews (items 10 and 12), and nuts that fasten the outer chambers (item 14), diaphragms (items 15 and 16) and intermediate bracket (item 4) together.

**Step #3:** Removing the diaphragm assemblies.

Use a 3/4" (19mm) wrench or six pointed socket to remove the diaphragm assemblies (outer plate, diaphragm, and inner plate) from the diaphragm rod (item 32) by turning counterclockwise.

Insert a 6-32 set screw into the smaller tapped hole in the inner diaphragm plate (item 29). Insert the protruding stud and the 6-32 fastener

loosely into a vise. Use a 3/4" wrench or socket to remove the outer diaphragm plate (item 28) by turning counterclockwise. Inspect the diaphragms (item 15 and 16) for cuts, punctures, abrasive wear or chemical attack. Replace the diaphragms if necessary.

**Step #4:** Installing the diaphragms.

Push the threaded stud of the outer diaphragm plate through the center hole of the diaphragm. Thread the inner plate clockwise onto the stud. Insert the loose assembly with the above 6-32 fastener back into the vise. Use a torque wrench to tighten the diaphragm assembly together to 7.5 ft. Lbs. (10.17 Newton meters). Allow a minimum of 15 minutes to elapse after torquing, then re-torque the assembly to compensate for stress relaxation in the clamped assembly.

**Step #5:** Installing the diaphragm assemblies to the pump.

Make sure the bumper (item 6) is installed over the diaphragm rod.

Thread the stud of the one diaphragm assembly clockwise into the tapped hole at the end of the diaphragm rod (item 32) until the inner diaphragm plate is flush to the end of the rod. Insert rod into pump.

Align the bolt holes in the diaphragm with the bolt pattern in the intermediate (item 4).

Fasten the outer chamber (item 14) to the pump, using the capscrews (items 10 and 12) and flanged nuts.

On the opposite side of the pump, pull the diaphragm rod out as far as

possible. Make sure the bumper (item 6) is installed over the diaphragm rod.

Thread the stud of the remaining diaphragm assembly clockwise into the tapped hole at the end of the diaphragm rod (item 32) as far as possible and still allow for alignment of the bolt holes in the diaphragm with the bolt pattern in the inner chamber. Install diaphragms with convolutions facing towards center of pump. See sectional view on previous page.

Fasten the remaining outer chamber (item 14) to the pump, using the capscrews (items 10 and 12) and flanged nuts.


**Step #6:** Re-install the elbow/spacer/manifold assemblies to the pump, using the capscrews (item 10 and 11) and flanged nuts.

The pump is now ready to be re-installed, connected and returned to operation.

## OVERLAY DIAPHRAGM SERVICING

The overlay diaphragm (item 16) is designed to fit snugly over the exterior of the standard TPE diaphragm (item 15).

Follow the same procedures described for the standard diaphragm for removal and installation.



## ! IMPORTANT

*Read these instructions completely, before installation and start-up. It is the responsibility of the purchaser to retain this manual for reference. Failure to comply with the recommendations stated in this manual will damage the pump, and void factory warranty.*

## CHECK VALVE SERVICING

Before servicing the check valve components, first shut off the suction line and then the discharge line to the pump. Next, shut off the compressed air supply, bleed air pressure from the pump, and disconnect the air supply line from the pump. Drain any remaining fluid from the pump. The pump can now be removed for service.


To access the check valve components, remove the manifold/manifold assembly. Use a 1/2" wrench or socket to remove the fasteners. Once the manifold is removed, the check valve components can be seen.

Inspect the check balls (items 2) for wear, abrasion, or cuts on the spherical surface. The check valve seats (item 34) should be inspected for cuts, abrasive wear, or embedded material on the surfaces of both the external and internal chambers. The spherical surface of the check balls must seat flush to the surface of the check valve seats for the pump to operate to peak efficiency. Replace any worn or damaged parts as necessary.

Re-assemble the check valve components. The seat should fit into the counter bore of the outer chamber.

The pump can now be reassembled, reconnected and returned to operation.

## Check Valve Drawing



## PUMPING HAZARDOUS LIQUIDS

When a diaphragm fails, the pumped liquid or fumes enter the air end of the pump. Fumes are exhausted into the surrounding environment. When pumping hazardous or toxic materials, the exhaust air must be piped to an appropriate area for safe disposal. See illustration #1 at right.

This pump can be submerged if the pump materials of construction are compatible with the liquid being pumped. The air exhaust must be piped above the liquid level. See illustration #2 at right. Piping used for the air exhaust must not be smaller than 1/2" (1.27 cm) diameter. Reducing the pipe size will restrict air flow and reduce pump performance. When the pumped product source is at a higher level than the pump (flooded suction condition), pipe the exhaust higher than the product source to prevent siphoning spills. See illustration #3 at right.

## CONVERTING THE PUMP FOR PIPING THE EXHAUST AIR

The following steps are necessary to convert the pump to pipe the exhaust air away from the pump.

Use a Phillips screwdriver to remove the six self-tapping screws (item 1-H).

Remove the muffler cap and muffler (items 1-G and 1-F). The 3/8" NPT molded threads in the air distribution valve body (item 1-A).


Piping or hose may now be installed.

## IMPORTANT INSTALLATION NOTE:

The manufacturer recommends installing a flexible hose or connection between the pump and any rigid plumbing. This reduces stresses on the molded plastic threads of the air exhaust port. Failure to do so may result in damage to the air distribution valve body.

Any piping or hose connected to the pump's air exhaust port must be physically supported. Failure to support these connections could also result in damage to the air distribution valve body.

## Exhaust Conversion Drawing



## CONVERTED EXHAUST ILLUSTRATION

