

FlowMaster™ Rotary Driven Hydraulic Pump
Models: 85480, 85481, 85482, 85483,
Series “B”
Models: 85247, 85610, 85586
Series “A”



U.S. Patent No. 6,102,676

Foreign Patent Pending



This pump conforms to the European Directive for Product Safety

Table of Contents

	Page
Safety.....	2
Description.....	2
Appropriate Use.....	2
Pump Performance and Specifications.....	3
Installing the Pump.....	4
Operation.....	5
Maintenance and Repair.....	5
Pump Dimensions.....	7
Repair Parts List.....	9
Trouble Shooting.....	10

Safety

Read and carefully observe these operating instructions before unpacking and operating the pump! The pump must be operated, maintained and repaired exclusively by persons familiar with the operating instructions. Local safety regulations regarding installation, operation and maintenance must be followed.

Operate this pump only after safety instructions and this service manual are fully understood.



Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.




Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

Safety Instructions

This equipment generates very high grease pressure. Extreme caution should be used when operating this equipment as material leaks from loose or ruptured components can inject fluid through the skin and into the body causing serious bodily injury. Adequate protection is recommended to prevent splashing of material onto the skin or into the eyes.

If any fluid appears to penetrate the skin, get emergency



medical care immediately. Do not treat as a simple cut. Tell attending physical exactly what fluid was injected.

Inspection

If overpressurizing of the equipment is believed to have occurred, contact the factory authorized warranty and service center nearest you for inspection of the pump.

Specialized equipment and knowledge is required for repair of this pump. Contact the factory authorized warranty and service center nearest you for repair or adjustments other than maintenance specified in this manual.

Annual inspection by the factory authorized warranty and service center nearest you is recommended.

A list of factory authorized warranty and service centers is available upon request.

Damaged Pumps

Any pump that appears to be damaged in any way, is badly worn or operates abnormally, shall be removed from use until repairs are made. Contact the factory authorized warranty and service center nearest to you for repairs.

Description

- 85480 - Pump for 120 pound drum (16 gallon)
- 85481 - Pump for 60 pound drum
- 85482 - Pump for 400 pound drum (55 gallon)
- 85483 - Pump for 5 gallon pail
- 85247 - Similar to 85480, but with a manual override
- 85610 - Low Temperature Pump for 400 lb. drum (55 gallon)
- 85586 - Heavy Duty pump for 400 lb. drum

General Description

The Lincoln Industrial rotary Hydraulic Pump is a fully hydraulically operated grease pump. Grease output is proportional to the hydraulic input flow. The pump is primarily designed for centralized lubrication systems such as the Single Line parallel, Single Line Progressive and Two Line systems. An integrated pump control manifold is incorporated with the motor to control input flow and pressure. A 24 volt DC solenoid valve is also incorporated as a method to turn the pump on and off. A 24 volt DC solenoid valve with a manual override is standard on model 85247 and is an option on other models.

The pump is driven by the rotary motion of the hydraulic motor. Rotary motion is converted to reciprocating motion through an eccentric crank mechanism. The reciprocating action causes the pump cylinder to move up and down. The unit is a positive displacement double acting pump as grease output occurs during both the up and down stroke.

During the down stroke, the pump cylinder is extended into the grease. Through the combination of shovel action and vacuum generated in the pump cylinder chamber, the grease is forced into the pump cylinder. Simultaneously, grease is discharged through the outlet of the pump. The volume of grease during intake is twice the amount of grease output during one cycle. During the upstroke, the inlet check closes, and one half of the grease taken in during the previous stroke is transferred through the outlet check and discharged to the outlet port. Typical output of the pump is shown on page 4.

Appropriate Use

- All pump models are exclusively designed to pump and dispense lubricants using hydraulic power.
- The maximum specification ratings should not be exceeded.
- Any other use not in accordance with instructions will result in loss of claims for warranty and liability.

FlowMaster™ Rotary Driven Hydraulic Pump




Illustration 1

Pump Performance and Specification

Supply inlet hydraulic pressure, maximum, PSIG (bar) - **3,500 (241)**
 Operating working hydraulic pressure, PSIG (bar) - **300 to 450 (20 to 32).**
 Hydraulic Inlet Flow, GPM (l/min) - **Up to 7 (28)**
 Pump Ratio with manifold - **9:1 at low inlet pressure (300 to 350 psi [20 to 25 bar]) and low inlet flow (below 2 gpm [7 lpm])**
Pump ratio approaches 11.0:1 ratio at higher inlet pressure and flow.

Operating Temperature, °F (°C) - **-20 to +150 (-29 to 65)****
 Operating Voltage, VDC - **24**
 Hydraulic Inlet Port, In - **SAE 4**
 Tank Return Port, In - **SAE 6**
 Pump Outlets, In - **1/4 NPTF**
 Maximum Hydraulic Fluid Temperature, °F, (°C) - **250 (121)**
 Weight, Lbs (Kg) - **36 (16)**



Do not exceed 3,500 PSIG (241 bar) maximum supply inlet hydraulic pressure. Exceeding the rated pressure may result in damage to system components and personal injury.

HYDRAULIC PUMP PERFORMANCE SPECIFICATIONS


Test conducted with Alvania NLGI # 2 Grade Grease

Temperature F (Temperature C)	Grease Output Cubic inches/min. (cm ³ /min.)				1,000 psi Backpressure (70 bar)			
	Hydraulic Flow Input							
	1 gpm (4 l/min)	2 gpm (8 l/min)	3 gpm (11 l/min)	4 gpm (15 l/min)	5 gpm (19 l/min)	6 gpm (23 l/min)	7gpm (26 l/min)	
80 (27)	7 (115)	14 (229)	21 (344)	28 (459)	34 (557)	40 (656)	45 (737)	
40 (4)	7 (115)	14 (229)	21 (344)	28 (459)	33 (541)	38 (623)	41 (642)	
20 (-7)	6 (98)	13 (213)	17 (279)	22 (361)	28 (459)	32 (594)	36 (590)	
0 (-18)	6 (98)	11 (180)	15 (245)	19 (310)	23 (376)	27 (442)	30 (491)	
-10 (-23)	5 (82)	7 (115)	8 (131)	9 (148)	10 (164)	12 (197)	13 (213)	
-20 (-29)	4 (66)	6 (98)	8 (131)	10 (164)	12 (197)	14 (229)	15 (245)	


*Solenoid valve with manual override standard on Model 85247, optional on other models.

** 85610 Operating Temperature, ° F(°C) is -70 to 150 (-57 to 65)

Grease Output vs. Hydraulic Input



Grease Output vs. Hydraulic Input



Installing the Pump

Typical installation is shown only as a guide for selecting and installing system components. Contact your Lincoln Industrial representative for assistance in designing a system to suit your specific needs.

The pump was tested in light weight oil which was left in to protect the pump from corrosion. Flush the pump before connecting it to the system to prevent contamination of the grease with residual oil.

The pump has flow and pressure controls integrated into the manifold (37). A normally closed **ON/OFF** Solenoid Valve (35) is also integrated into the manifold and will start or stop the pump operation.

1. Mount the pump securely on the drum cover so that it cannot move or vibrate during operation.
2. Attach hydraulic supply line to the **Inlet** and return line to the **Tank** ports.
3. Connect material supply line to the pump outlet. Plug the unused outlet on opposite side of the pump.
4. Install high pressure shut-off valve in the material supply line. (Required)
5. Connect 24 VDC power supply to the solenoid valve (35). See Illustration #1. Use connector plug (36) supplied with the pump.

NOTE: To install the pump Model 85481 as a replacement pump for 84961 used on Model 84944, use adapter/spacer kit p/n 272013 with bolts p/n 50014, included in the pump package (see illustration #4).




Illustration 3

- A - Pump Outlet Plug
- B - Hydraulic Supply Line
- C - Hydraulic Return to Tank line (3/4" ID min.)
- D - Supply Line Shut-off Valve
- E - 24 VDC from Controller
- F - Return Line Shut-off Valve (3/4" ID min.)
- G - Vent Valve Port with Restrictor
- H - Outlet Shut-off Valve
- J - Material Supply Line
- K - Follower Plate (85492 for 120 lb. drum only)
- L - Drum Cover (83115 for 400 lbs., 84616 for 120 lbs.)




Illustration 4

* Included in Spacer Kit 272013



Mount the pump securely on the drum cover. Failure to do so could result in personal injury and equipment damage.



Do not exceed 450 PSIG (32 bar) working hydraulic pressure. Use high pressure components to reduce risk of serious injury including fluid injection and splashing in the eyes or on the skin. All accessories connected to the pump outlet must have at least 5,000 PSIG (350 bar) minimum hydraulic pressure. All accessories connected to the pump inlet must have at least 3,500 PSIG (241 bar) minimum working pressure.

Operation

All pumps are factory set at 350 PSIG (24 bar) working inlet hydraulic pressure with a flow rate of 2.5 GPM (9.5 l/min).

Do not change the settings for the pump until after the start up procedure.

1. Shut off the material supply line valve.
2. Turn on the hydraulic pressure.
3. Energize the solenoid **On/Off** valve.
4. Prime the pump by slowly opening the shut-off lubricant supply line valve. Make sure that all air has been expelled from the pump and even lubricant flow is achieved.
5. Adjust the pump pressure and flow to the desired application requirements. See **Pressure and Flow Control Valve Adjustment** for instructions to adjust pressure and flow. Do not exceed pump operating pressure of 450 PSIG (32 bar).
6. Always use the lowest pump output pressure and hydraulic fluid flow to obtain the desired results. This will reduce the pump wear.



Do not exceed maximum operating temperature of the hydraulic fluid (250° F/121° C) . Never allow the pump to run dry of lubricant. A dry pump quickly speeds up, creating friction heat, which can damage the seals. Monitor the supply lubricant level and refill when necessary.

Setting the Pump Manifold Pressure and Flow Controls

The pressure must first be adjusted to insure the desired flow setting is achieved.

Pressure Control Valve Adjustment

- Loosen the lock nut on the Pressure control by turning the nut COUNTERCLOCKWISE.
- Turn the valve stem COUNTERCLOCKWISE until it no longer turns. The valve stem will unscrew until it reaches the stop. It will not come off. This is the minimum pressure setting, which is about 170 psi (12 bar).
- With the pump stalled against pressure, turn the Pressure Control Valve stem CLOCKWISE until the desired pressure is attained on the manifold Pressure Gage. (Do not exceed 450 PSI.
- Tighten the lock nut by turning CLOCKWISE.

Flow Control Valve Adjustment

- Loosen the lock nut on the Flow Control Valve by turning the nut COUNTERCLOCKWISE.
- Adjust the flow by turning the valve stem CLOCKWISE to reduce the flow and COUNTERCLOCKWISE to increase it. The Flow Control Valve can be turned in until the valve is completely closed, and out a maximum of 2 1/2 turns. The valve stem will not come out when fully open (unscrewed) as there is a stop at this position.
- After adjusting the flow to the desired setting, tighten the lock nut by turning it CLOCKWISE.

Maintenance and Repair

Relieve pressure from the pump and supply lines before servicing or repairing the pump, to reduce the risk of an injury from injection, splashing fluid or moving parts.



Always use Lincoln Industrial parts for service and repair.

Crank Case Oil

Check the oil after every 100 hours of operation. The crankcase should be filled to the center of the drain plug located on the back of the crankcase. Change the oil after every 500 hours of operation. Use SAE 10W30 motor oil in all units except 85610. In 85610, use Mobil Arrow HFA Low Temp oil for use at -70°F ambient temperatures.

Disassembly Procedure (See illustration #6)

Tools Required:

- Hex Bit Socket Wrenches (3/8" square drive) with 3/8" hex, 5/32" hex, 1/4" hex.
- 3/8" O.D. Steel Rod
- 12" Crescent Wrench
- Spanner Wrench (for 3/8" diameter tube, 1/8" pin)
- 1/2" to 3/8" square drive adapter
- Torque wrench (1/2" square drive, 0 - 50 ft-lb capacity)
- Torque wrench (3/8" square drive, 0 - 120 in-lb capacity)
- 1/4" nut driver

1. Remove the four Socket Head Screws (33) and separate Manifold from the Hydraulic Motor (42).
2. Remove Pipe Plug (45) and drain the crankcase oil from the Pump Housing (46).
3. Remove six self-threading Screws (29) and remove the Housing Cover (30) and the Cover Gasket (31).
4. Remove Retaining Ring (57) and pull the Shovel Plug (56) from the Housing Tube (55).
5. Remove two Socket Head Screws (44) and separate the Hydraulic Motor (42) from the Pump Housing (46).
6. Remove two Outlet Pin Nuts (50) from the Pump Housing (46).
7. Remove the Pump Subassembly (1 through 28) from the Pump Housing (46). Pushing the subassembly up with a wooden or plastic rod 3/4 O.D. against the Check Seat Housing (28) is helpful.
8. Remove the Housing Tube (55) from the Pump Housing (46) by inserting a 3/4 rod through the inlet holes at the bottom of the Housing Tube (55) and unscrewing it.
9. Remove the Bronze Bearing (51), the O-Ring (52), and the Backup Washer (53) from the Housing Tube (55).
10. Remove the Crankrod Assembly (1 through 8) from the pump by unscrewing the Button Head Screws (12) and then pulling out the Wrist Pin Bushings (13).
11. Remove the Check Seat Housing (28) from the Reciprocating Tube (21). There is a 3/8 Allen Head socket in the throat of the Check Seat Housing (28) to facilitate removal.
12. Unscrew the Wrist Pin Anchor (14) from the Reciprocating Tube (21) and pull the Plunger Assembly (9 through 20) from the tube.
13. Using a 1/2" wooden or plastic rod, push the Cup Seal (22) and the Pump Cylinder (24) from the Reciprocating Tube (21).
14. Remove the Pump Plunger (20) from the Plunger Link Rod (17). A spanner wrench, which uses the holes in the Pump Plunger, is required.
15. Unscrew the Plunger Link Rod (17) from the Plunger Tube (11) and slide off the Cup Seal (16), the Backup Washer (15) and the Wrist Pin Anchor (14).
16. Unscrew the Plunger Tube (11) from the Outlet Pin (9).
17. To dismantle the Crankrod Assembly (1 through 8), remove Flat Head Screws (1) and the Counter Weights (2).
18. Remove the Retaining Rings (6) and press the Crank Eccentric (7) out of the Ball Bearing (8). Be sure to support the Ball Bearing (8) on the inner race.

Pump Assembly Procedure

1. When the pump is disassembled, it is recommended to replace all seals and gaskets, which are included in the 270663 repair kit.
2. In the process of disassembly, examine the following components and replace if excessive wear is indicated: Ball Bearing (8), Crank Eccentric (7), Crankrod (5), Wrist Pin Bushings (13), Plunger Tube (11), Pump Plunger and Upper Check Parts (20, 19 and 18), Pump Cylinder (24), Check Seat Housing and Lower Check Ball (28 and 26), upper Bronze Bushing (51), Housing Tube (55), Shovel Plug (56), and Reciprocating Tube (21).
3. Assembly Procedure is the reverse of the Disassembly Procedure except for the following:
4. Install parts (22) through (28) into the Reciprocating Tube (21) after the plunger assembly (9 through 20) is installed.
5. Install the Pump Subassembly (1 through 28) into the Pump Housing (46) before tightening the Housing Tube (55) to the Pump Housing (46). Be sure the Reciprocating Tube (21) is inserted through both bushings before tightening the Housing Tube (55).
6. Use loctite 242 (or similar product) medium strength thread lock on all torqued threaded connections. Extreme care must be exercised to prevent excess compound from flowing into critical areas such as clearance fits and ball check. Allow a minimum of 30 minutes cure time before operating the pump.
7. Torque Specifications:
 - A. Plunger Tube (11) to Outlet Pin (9) - 100 to 110 In.-Lbs.
 - B. Button Head Screws (12) to Wrist Pin Anchor (14) 100 to 110 In.-Lbs.
 - C. Plunger Tube (11) to Plunger Link Rod (17) - 100 to 110 In.-Lbs.
 - D. Plunger Link Rod (17) to Pump Plunger (20) - 100 to 110 In.-Lbs.
 - E. Flat Head Screws (1) to Counter Weight (2) - 100 - 110 In.-Lbs.
 - F. Wrist Pin Anchor (14) to Reciprocating Tube (21) - 20 to 25 Ft.-Lbs.
 - G. Check Seat Housing (28) to Reciprocating Tube (21) - 20 to 25 Ft.-Lbs.
 - H. Outlet Pin Nut (50) to Pump Housing (46)© - 30 to 35 Ft.-Lbs.
 - I. Housing Tube (55) to Pump Housing (46)© - 20 to 25 Ft.-Lbs.
 - © J. Socket Head Screw (44) to Pump Housing (46) - 50 to 55 Ft. Lbs (be sure to use 271501 lock washers).
 - K. Pressure Reducing Valve (38) to Manifold (37) - 20-25 Ft. Lbs.
 - L. Flow Control Valve (39) to Manifold (37) - 20 -25 Ft. Lbs.
 - © M. Solenoid Valve (34) to Manifold (37) - 15 -20 Ft. Lbs.
 - N. Socket Head Screws (33) to Manifold (37) - 20 - 25 Ft. Lbs.

© Indicates change

FlowMaster™ Rotary Driven Hydraulic Pump




8. For Models 85480, 85481, 85482, 85483 and 85247, fill crankcase with SAE 10W30 motor oil up to pipe plug (45) before fastening housing cover (30) and housing gasket (31). If pump will be used in very cold environments, use Mobil Arrow HFA Low Temperature Oil. This oil stays fluid even at -70°F.


For Model 85610, fill crankcase with lightweight Mobil Arrow HFA Hydraulic Oil up to pipe plug (45) before fastening housing cover (30) and housing gasket (31).

9. On 85586, replace inlet strainer (63).

FlowMaster™ Rotary Driven Hydraulic Pump



Fill with SAE 10W30 Motor Oil for Pumps 85480, 85481, 85482, 85483 and 85247. Fill with light weight Mobil Arrow HFA Hydraulic Oil for Pump 85610.



- 1. 1/4 NPTF Pump Outlets
- 2. SAE 4 Inlet Port
- 3. SAE 6 Tank Port
- 4. 1/4 NPTF Orifice fitting for Vent Valve Port
- 5. Solenoid Valve
- 6. Pressure Reducing Valve
- 7. Flow Control Valve
- 8. Pressure Gauge

MODEL	DIM "A" in (mm)	DIM "B" in (mm)
85480	27.50 (699)	38.56 (980)
85481	19.00 (483)	30.06 (764)
85482	34.00 (864)	44.94 (1142)
85483	13.69 (348)	24.75(629)
85247©	27.50 (699)	38.56 (980)
85586©	34.18 (868)	45.12 (1146)
85610©	34.00 (864)	45.06 (1145)




Illustration #5

FlowMaster™ Rotary Driven Hydraulic Pump




Illustration #6

Repair Parts List (Common to all Models)

Item No.	Qty	Description	All Models	Item No.	Qty	Description	All Models
1	2	Flat Head Screw (1/4 x 1-3/4)	270635	34	1	Solenoid Valve Cartridge (Note #2)	270690
2	2	Counter Weight	272197	or	1	Solenoid Valve Cartridge with Manual Override Knob	272112
4	2	Retaining Ring	270609				271918
5	1	Crankrod	270665	35	1	Solenoid Valve Coil (24 VDC)	270691
6	2	Retaining Ring	270608	36	1	Solenoid Connector	242209
7	1	Crank Eccentric	270666	37	1	Manifold	270771
8	1	Ball Bearing	270607	38	1	Pressure Reducing Valve (Note #3)	270692
9	1	Outlet Pin	270670	39	1	Flow Control Valve (Note #4)	270693
10	1	O-Ring (Nitrile)	*				
11	1	Plunger Tube	270667	40	2	O-Ring (Viton)	*
12	2	Button Head Screw (1/4 x 1/2)	270634	41	1	Motor Gasket	*
13	2	Wrist Pin Bushing	270668	42	1	Hydraulic Motor (Note #1)	270676
14	1	Wrist Pin Anchor	270669	43	2	Washer	271501
15	1	Backup Washer	*				
16	1	Cup Seal (Polyurethane)	*	44	2	Socket Head Screw (1/2 x 1-1/4)	270658
17	1	Plunger Link Rod	See Chart Below	45	1	Pipe Plug (3/8 NPTF)	67417
18	1	Spring	270616	46	1	Pump Housing	270673
19	1	Ball	66010	47	2	Backup Ring (Polyurethane)	*
20	1	Pump Plunger	270671	48	2	O-Ring (Polyurethane)	*
21	1	Reciprocating Tube	See Chart Below	49	2	O-Ring (Nitrile)	*
22	1	Cup Seal (Polyurethane)	*	50	2	Outlet Pin Nut	270619
23	1	O-Ring (Polyurethane)	*	51	1	Bronze Bearing	270674
				52	1	O-Ring (Polyurethane)	*
24	1	Pump Cylinder	270672	53	1	Backup Washer	*
25	1	Ball Cage	270675	54	1	O-Ring (Nitrile)	*
26	1	Ball	66001	55	1	Housing Tube	See Chart Below
27	1	O-Ring (Nitrile)	*	56	1	Shovel Plug	270707
28	1	Check Seat	270664	57	1	Retaining Ring	270705
29	6	Self-Threading Screw (8 x 1/2)	270633	58	1	Seal Kit (Nitrile)	270687
				59	1	Seal Kit (Nitrile)	270688
30	1	Housing Cover	270629	60	1	Seal Kit (Nitrile)	270689
31	1	Cover Gasket (Nitrile)	*	61	1	Orifice Fitting	270735
				62	6	Gasket	252986
32	1	Pressure Gauge	270768	63	1	Inlet Strainer	272180***
33	4	Socket Head Screw (5/16 x 1-1/4)	270680			Soft parts Kit	270663

Repair Parts List (Non-common items)

Item No.	Qty.	Description	Model 85480	Model 85481	Model 85482	Model 85483	Model 85586****	Model 85610**
17	1	Plunger Link Rod	270648	270614	270645	270641	270645	270645
21	1	Reciprocating Tube	270649	270617	270646	270642	272176	270646
55	1	Housing Tube	270659	270660	270661	270662	270661	270661
25	1	Ball Cage	270675	270675	270675	270675	272179	270675
38	1	Pressure Reducing Valve	270692	270692	270692	270692	272177	270692
39	1	Flow Control Valve	270693	270693	270693	270693	272178	270693

* Included in 270663 Soft Parts Kit.

** This Model is similar to 85482, except that the crankcase is filled with Mobil Arrow HFA Low Temperature Oil.

*** The inlet strainer fits on all FlowMaster models.

**** This model is similar to 85482, several internal parts

are made more robustly for longer life.

1. Includes Gasket (Item 41) and O-Rings (Item 40).

2. Includes Seal Kit (Item 58).

3. Includes Seal Kit (Item 59).

4. Includes Seal Kit (Item 60).

Troubleshooting

Condition	Possible Cause	Corrective Action
Pump does not run.	No pressure on gauge (32): - Closed Supply line shut off valve. - No power to solenoid valve (34). - Faulty Solenoid (35). - Pressure Reducing Valve (38) is set too low. - Insufficient Hydraulic Fluid supply.	Open shut-off valve. Correct electrical fault. Replace solenoid (35). Reset Pressure Reducing Valve (38). Check hydraulic supply for proper pressure and flow.
	Pressure is shown on gauge (32): - Closed Fluid outlet line. - Flow Control valve is fully closed. - Pump is stalled due to grease backpressure.	Check outlet line and clear obstructions. Readjust valve to 3/4 turn open. Check vent valve in system.
	Pump is seized or damaged.	Dismantle the pump and repair defective or seized component. See disassembly and assembly procedure.
Pump speeds up or runs erratically.	Low level of grease or reservoir is empty	Refill reservoir.
	Follower plate is stuck and separated from grease.	Check follower plate and container for damage.
	Pump piston or checks are worn.	Disassemble the pump and repair.
Pump runs, but output is low.	Insufficient hydraulic fluid supply.	Check hydraulic supply and adjust flow using valve (39).
	Inlet pressure too low.	Increase pressure using valve (38).
	Faulty inlet (25, 26, 27) or discharge check valve (18, 19, 20).	Replace faulty components.
Weepage from housing cover 30.	Cup seal (16) or O-Ring (48) wore out.	Check the seals and replace if necessary.
Pump becomes noisy.	No crank case oil.	Add crank case oil. Remove Pipe Plug (45) from Pump Housing (46). Oil level should be at the bottom of the Pipe Plug opening. For Models 85480, 85481, 85482, 85483 and 85247 Add 10W30 motor oil until the crankcase is full. For Model 85610, add light weight Mobil Arrow HFA Hydraulic Oil until the crankcase is full.
	Worn wrist pin bushing (13).	Check the bushings and replace if necessary.
Pump dies not build pressure.	Foreign material holding lower check open.	Dismantle & clear check. Consider installing inlet screen 272180 before returning pump to service.

FlowMaster™ Rotary Driven Hydraulic Pump



Lincoln Industrial
One Lincoln Way
St. Louis, MO 63120-1578
(+1) 314 679 4200

Lincoln GmbH
69190 Walldorf
Heinrich-Hertz Strasse 2-8
(+49) 6227 33-0

Lincoln Industrial
25 International Business Park
#01-68 German Centre
Singapore 609916
(+65) 562-7960

© Copyright 2002
Printed in USA

Web site:
www.lincolnindustrial.com