


FlowMaster™ Electric Pump
Models: 85578 and 85579, 24 VDC, 100 RPM
85580, 90 VDC, 100 RPM
85582, 12 VDC, 300 RPM
Series "A"



U.S. Patent No. 6,102,676



Foreign Patent Pending

This pump conforms to the European Directive for Product Safety



Table of Contents

| | Page |
|--|------|
| Safety | 2 |
| Description..... | 2 |
| Appropriate Use..... | 2 |
| Pump Performance and Specifications..... | 3 |
| Installing the Pump..... | 4 |
| Operation..... | 5 |
| Maintenance and Repair..... | 5 |
| Pump Dimensions..... | 7 |
| Repair Parts List..... | 9 |
| Trouble Shooting..... | 10 |

Safety


Read and carefully observe these operating instructions before unpacking and operating the pump. The pump must be operated, maintained and repaired exclusively by persons familiar with the operating instructions. Local safety regulations regarding installation, operation and maintenance must be followed.

Operate this pump only after safety instructions and this service manual are fully understood.



Safety Instructions

This equipment generates very high grease pressure. Extreme caution should be used when operating this equipment as material leaks from loose or ruptured components can inject fluid through the skin and into the body causing serious bodily injury. Adequate protection is recommended to prevent splashing of material onto the skin or into the eyes.



Inspection

If overpressurizing of the equipment is believed to have occurred, contact the factory authorized warranty and service center nearest you for inspection of the pump.

Specialized equipment and knowledge is required for repair of this pump. Contact the factory authorized warranty and service center nearest you for repair or adjustments other than maintenance specified in this manual.

Annual inspection by the factory authorized warranty and service center nearest you is recommended.

A list of factory authorized warranty and service centers is available upon request.

Damaged Pumps

Any pump that appears to be damaged in any way, is badly worn or operates abnormally, shall be removed from use until repairs are made. Contact the factory authorized warranty and service center nearest to you for repairs.

Description

- 85578 - Pump for 400 pound drum (55 gallon), 24 VDC, 100 RPM
- 85579 - Pump for 5 gallon pail, 24 VDC, 100 RPM
- 85580 - Pump for 5 gallon pail, 90 VDC, 100 RPM
- 85582 - Pump for 60 pound container, 12 VDC, 300 RPM

General Description

The Lincoln Industrial Electric Pump can operate on 12, 24 or 90 VDC. The pump is primarily designed for railroad lubrication and can be used for centralized lubrication systems such as the Single Line Parallel*, Single Line Progressive and Two Line systems. Pressure relief valve or pressure switch or both should be included into the system installation. See Illustration 1 for possible installation schematic.

*Note: Centro-Matic Single Line Parallel system will require an electric operated vent valve. The line pressure has to be vented between lubrication cycles to allow the injector valves to recharge. An electrically operated 2-way solenoid valve is required for this purpose. Consult Lincoln Industrial Technical Services for recommendations. See Figure 2.


The pump is driven by the rotary motion of the electric DC gear motor. Rotary motion is converted to reciprocating motion through an eccentric crank mechanism. The reciprocating action causes the pump cylinder to move up and down. The pump is a positive displacement double acting pump as grease output occurs during both the up and down stroke of the pump.

During the down stroke, the pump cylinder is extended into the grease. Through the combination of shovel action and vacuum generated in the pump cylinder chamber, the grease is forced into the pump cylinder. Simultaneously, grease is discharged through the outlet of the pump. The volume of grease during intake is twice the amount of

FlowMaster™ Electric Pump

LINCOLN
INDUSTRIAL®

**Typical Installation Schematic
For Single Line Progressive and Two Line systems.**



1. Electric Flow Master Pump
2. Pressure Switch
3. Pressure Relief Valve
4. Grease Reservoir

Illustration 1

* Use #10 wire on 12 Volt pump power wiring

grease output during one cycle. During the upstroke, the inlet check closes, and one half of the grease taken in during the previous stroke is transferred through the outlet check and discharged to the outlet port.

Appropriate Use

- All pump models are exclusively designed to pump and dispense lubricants using electrical power.
- The maximum specification ratings should not be exceeded.
- Any other use not in accordance with instructions will result in loss of claims for warranty and liability.




Figure 2

- | |
|--|
| A - Pump Outlet Plug |
| B - Controller/Timer* |
| C - Pressure Switch |
| D - Pressure Relief Valve |
| E - Wire connections from controller/timer |
| F - Pressure Gage |
| G - Material Supply Line |
| H - Follower Plate (85493 for 400 lb. drum only) |
| J - Drum Cover (83115 for 400 lbs.) |
| K - Wire connection to Relief (Vent) valve |
| L - Vent Tube |

* Controller/Timer should be rated to carry appropriate current per pump performance specifications. External relay can be used with low current controller/relay.

Pump Performance and Specification

| | |
|----------------------------------|-----------------------------|
| Outlet Pressure, Max. - | 3500 PSIG (240 bar) |
| Motor Enclosure - | TENV |
| Operating Temperature, °F (°C) - | -20 to +150 (-10 to +65) |
| Pump Outlets, In. - | 1/4 NPTF |
| Weight, Lbs (kgs)- | 36 (16) |
| * Use #10 wire | |

| Model | Grease Output @ 1000 psi (70 bar) in³/Min (cm³/min) | RPM | Operating Voltage | Current @ 3,500 psig (Amp) | Pump Size |
|-------|--|-----|-------------------|-------------------------------|-----------|
| 85578 | 7.0 (108.0) | 100 | 24 VDC | 6.2 | 55 Gal. |
| 85579 | 7.0 (108.0) | 100 | 24 VDC | 6.2 | 5 gal. |
| 85580 | 7.0 (108.0) | 100 | 90 VDC | 1.7 | 5 gal. |
| 85582 | 21 (324) | 300 | 12 VDC | 31.0* | 60 lbs. |

A WARNING

Do not stall the pump under pressure. Always use relief valve and pressure switch to stop the pump if lubricant pressure exceeds specification.

Installing the Pump

Typical installation is shown only as a guide for selecting and installing system components. Contact your Lincoln Industrial representative for assistance in designing a system to suit your specific needs.

The pump was tested in light weight oil which was left in to protect the pump from corrosion. Flush the pump before connecting it to the system to prevent contamination of the grease with residual oil.

1. Mount the pump securely on the drum cover so that it cannot move or vibrate during operation.
2. Connect motor of the pump to 24 VDC for 85578 and 85579, 90 VDC for 85580, or 12 VDC for 85582 power supply. On the 12 VDC motor, wire to the connection box using #10 wire.
3. Connect material supply line to the free pump outlet. Factory installed plug can be removed to use the other outlet instead of open one if desired.
4. Lincoln Industrial recommends installing a lubricant "bleed off" valve. The valve location should be at the end of the lubricant supply line. Depending on application, the valve could be manual or automatically operated. "Bleed off" material each time the lubricant supply drum/reservoir is changed.

A WARNING

Mount the pump securely on the drum cover. Failure to do so could result in personal injury and equipment damage.

A WARNING

Use high pressure components to reduce risk of serious injury including fluid injection and splashing in the eyes or on the skin. All accessories connected to the pump outlet must have at least 5,000 PSIG (350 bar) minimum hydraulic pressure.

Operation

1. Start the pump and prime the lubricant supply lines.
2. Make sure that all air has been expelled from the pump and supply lines and even lubricant flow is achieved.
3. Set the pressure switch and relief valve at pressures 10 to 15% above operating pressure. Check if pressure switch will stop the pump and relief valve will open to relieve pressure if it exceeds the preset pressure.

Maintenance and Repair

Relieve pressure from the pump and supply lines before servicing or repairing the pump to reduce the risk of an injury from injection, splashing fluid or moving parts.

A WARNING

Always use Lincoln Industrial parts for service and repair.

Disassembly Procedure (See illustration #6)

Tools Required:

- Hex Bit Socket Wrenches (3/8" square drive) with 3/8" hex, 5/32" hex, 1/4" hex.
 - 3/8" O.D. Steel Rod
 - 12" Crescent Wrench
 - Spanner Wrench (for 3/8" diameter tube, 1/8" pin)
 - 1/2" to 3/8" Square Drive Adapter
 - Torque Wrench (1/2" Square Drive, 0 - 50 ft-lb capacity)
 - Torque Wrench (3/8" Square Drive, 0 - 120 in-lb capacity)
 - 1/4" Nut Driver
 - Screwdriver (flat blade, 1/8" blade width)
1. Remove Pipe Plug (38) and drain the crankcase oil from the Pump Housing (39).
 2. Remove six self-threading Screws (29) and remove the

- Housing Cover (30) and the Cover Gasket (31).
3. Remove Retaining Ring (51) and pull the Shovel Plug (50) from the Housing Tube (48).
 4. Remove four Socket Head Screws (37) and separate the Gear Motor (36) from the Pump Housing Adapter (33).
 5. Remove Flat Head Screws (34) and remove Adapter Plate (33) from Housing (39).
 6. Remove Seal (35) from Adapter Plate (33).
 7. Remove two Outlet Pin Nuts (43) from the Pump Housing (39).
 8. Remove the Pump Subassembly (1 through 28) from the Pump Housing (39). Pushing the Subassembly up with a wooden or plastic rod 3/4 O.D. against the Check Seat Housing (28) is helpful.
 9. Remove the Housing Tube (48) from the Pump Housing (39) by inserting a 3/4 rod through the inlet holes at the bottom of the Housing Tube (48) and unscrewing it.
 10. Remove the Bronze Bearing (44), the O-Ring (45), and the Backup Washer (46) from the Housing Tube (48).
 11. Remove the Crankrod Assembly (1 through 8) from the pump by unscrewing the Button Head Screws (12) and then pulling out the Wrist Pin Bushings (13).
 12. Remove the Check Seat Housing (28) from the Reciprocating Tube (21). There is a 3/8 Allen Head socket in the throat of the Check Seat Housing (28) to facilitate removal.
 13. Unscrew the Wrist Pin Anchor (14) from the Reciprocating Tube (21) and pull the Plunger Assembly (9 through 20) from the Tube.
 14. Using a 1/2" wooden or plastic rod, push the Cup Seal (22) and the Pump Cylinder (24) from the Reciprocating Tube (21).
 15. Remove the Pump Plunger (20) from the Plunger Link Rod (17). A Spanner Wrench, which uses the holes in the Pump Plunger, is required.
 16. Unscrew the Plunger Link Rod (17) from the Plunger Tube (11) and slide off the Cup Seal (16), the Backup Washer (15) and the Wrist Pin Anchor (14).
 17. Unscrew the Plunger Tube (11) from the Outlet Pin (9).
 18. To dismantle the Crankrod Assembly (1 through 8), remove Flat Head Screws (1) and the Counter Weights (2)©.
 19. Remove the large Retaining Rings (6) and press the Crank Eccentric (7) out of the Ball Bearing (8). Be sure to support the Ball Bearing (8) on the inner race.

Procedure except for the following:

4. Install parts (22) through (28) into the Reciprocating Tube (21) after the plunger assembly (9 through 20) is installed.
 5. Install the Pump Subassembly (1 through 28) into the pump Housing (39) before tightening the Housing Tube (48) to the Pump Housing (39). Be sure the Reciprocating Tube (21) is inserted through both bushings before tightening the Housing Tube (48).
 6. Refill crank case with oil and install cover (30).
 7. Use loctite 242 (or similar product) medium strength thread lock on all torqued threaded connections. Extreme care must be exercised to prevent excess compound from flowing into critical areas such as clearance fits and ball check. Allow a minimum of 30 minutes cure time before operating the pump.
8. Torque Specifications:
- A. Plunger Tube (11) to Outlet Pin (9) - 100 to 110 In.-Lbs.
 - B. Button Head Screws (12) to Wrist Pin Anchor (14) 100 to 110 In.-Lbs.
 - C. Plunger Tube (11) to Plunger Link Rod (17) - 100 to 110 In.-Lbs.
 - D. Plunger Link Rod (17) to Pump Plunger (20) - 100 to 110 In.-Lbs.
 - E. Flat Head Screws (1) to Counter Weight (2)© - 100 - 110 In.-Lbs.
 - F. Wrist Pin Anchor (14) to Reciprocating Tube (21) - 20 to 25 Ft.-Lbs.
 - G. Check Seat Housing (28) to Reciprocating Tube (21) - 20 to 25 Ft.-Lbs.
 - H. Outlet Pin Nut (43) to Pump Housing (39) - 30 to 35 Ft.-Lbs.
 - I. Housing Tube (48) to Pump housing (39) - 20 to 25 Ft.-Lbs.


Pump Assembly Procedure

1. When the pump is disassembled, replacement of all seals and gaskets is recommended. These parts are included in the 270663 repair kit.
2. In the process of disassembly, examine the following components and replace if excessive wear is indicated: Ball Bearing (8), Crank Eccentric (7), Crankrod (5), Wrist Pin Bushings (13), Plunger Tube (11), Pump Plunger and Upper Check Parts (20, 19 and 18), Pump Cylinder (24), Check Seat Housing and Lower Check Ball (28 and 26), upper Bronze Bushing (44), Housing Tube (48), Shovel Plug (50), and Reciprocating Tube (21).
3. Assembly Procedure is the reverse of the Disassembly


© indicates change.

FlowMaster™ Electric Pump

LINCOLN
INDUSTRIAL®




| | 85578 | 85579 | 85580 | 85582 |
|---|-----------------|----------------------|----------------------|-----------------------|
| A | 42 (1067 mm) | 21 11/16 (551 mm) | 21 11/16 (551 mm) | 27 1/16" (687 mm) |
| B | 34 (864 mm) | 13 5/8 (346 mm) | 13 5/8 (346 mm) | 18 15/16" (481 mm) |



FlowMaster™ Electric Pump

LINCOLN
INDUSTRIAL®



Repair Parts List

(Common to all Models)

| Item No. | Qty | Description | All Models | Item No. | Qty | Description | All Models |
|----------|-----|-------------------------------|-----------------|----------|-----|--------------------------------|-----------------|
| 1 | 2 | Flat Head Screw (1/4 x 1-3/4) | 270635 | 26 | 1 | Ball | 66001 |
| 2 | 2 | Counter Weight© | 272197© | 27 | 1 | O-Ring (Nitrile) | * |
| 4 | 2 | Retaining Ring | 270609 | 28 | 1 | Check Seat | 270664 |
| 5 | 1 | Crankrod | 270665 | 29 | 6 | Self-Threading Screw (8 x 1/2) | 270633 |
| 6 | 2 | Retaining Ring | 270608 | 30 | 1 | Housing Cover | 270629 |
| 7 | 1 | Crank Eccentric | 270666 | 31 | 1 | Cover Gasket (Nitrile) | * |
| 8 | 1 | Ball Bearing | 270607 | 32 | 1 | Motor Gasket | * |
| 9 | 1 | Outlet Pin | 270670 | 33 | 1 | Adaptor Plate | 252851 |
| 10 | 1 | O-Ring (Nitrile) | * | 34 | 2 | Flathead Screws | 252854 |
| 11 | 1 | Plunger Tube | 270667 | 35 | 1 | Seal | 252864 |
| 12 | 2 | Button Head Screw (1/4 x 1/2) | 270634 | 36 | 1 | Gear motor | See Chart Below |
| 13 | 2 | Wrist Pin Bushing | 270668 | 37 | 4 | Cap Screws | 252853 |
| 14 | 1 | Wrist Pin Anchor | 270669 | 38 | 1 | Pipe Plug (3/8 NPTF) | 67417 |
| 15 | 1 | Backup Washer | * | 39 | 1 | Pump Housing | 270673 |
| 16 | 1 | Cup Seal (Polyurethane) | * | 40 | 2 | Backup Ring (Polyurethane) | * |
| | | | * | 41 | 2 | O-Ring (Polyurethane) | * |
| 17 | 1 | Plunger Link Rod | See Chart Below | 42 | 2 | O-Ring (Nitrile) | * |
| 18 | 1 | Spring | 270616 | 43 | 2 | Outlet Pin Nut | 270619 |
| 19 | 1 | Ball | 66010 | 44 | 1 | Bronze Bushing | 270674 |
| 20 | 1 | Pump Plunger | 270671 | 45 | 1 | O-Ring (Polyurethane) | * |
| 21 | 1 | Reciprocating Tube | See Chart Below | 46 | 1 | Back-up Washer | * |
| 22 | 1 | Cup Seal (Polyurethane) | * | 47 | 1 | O-Ring (Nitrile) | * |
| | | | * | 48 | 1 | Housing Tube | See Chart Below |
| 23 | 1 | O-Ring (Polyurethane) | * | 49 | 1 | Housing Bushing | 270637 |
| | | | * | 50 | 1 | Shovel Plug | 270707 |
| 24 | 1 | Pump Cylinder | 270672 | 51 | 1 | Retaining Ring | 270705 |
| 25 | 1 | Ball Cage | 270675 | 52© | 6 | Gasket | 252986 |

* Included in 270663 Soft Parts Kit.

Repair Parts List

(Non-common items)

| Item No. | Qty. | Description | Model 85578, 400lbs. | Model 85579, 5 Gal. | Model 85580, 5 Gal. | Model 85582, 60 Lb. |
|----------|------|--------------------|-------------------------|------------------------|------------------------|------------------------|
| 17 | 1 | Plunger Link Rod | 270645 | 270641 | 270641 | 270614 |
| 21 | 1 | Reciprocating Tube | 270646 | 270642 | 270642 | 270617 |
| 48 | 1 | Housing Tube | 270661 | 270662 | 270662 | 270628 |
| 36 | 1 | Gear Motor | 252852 | 252852 | 252977 | 252975 |

© indicates change.

Troubleshooting

| Condition | Possible Cause | Corrective Action |
|-------------------------------------|--|--|
| Pump does not run. | No power to motor. | Check power circuit. |
| | Power is applied to motor. - Pump is stalled due to grease backpressure | Check vent valve in system. |
| | Pump is seized or damaged. | Dismantle the pump and repair defective or seized component. See disassembly and assembly procedure. |
| Pump speeds up or runs erratically. | Low level of grease or reservoir is empty. | Refill reservoir. |
| | Follower plate is stuck and separated from grease. | Check follower plate and container for damage. |
| | Pump piston or checks are worn. | Disassemble the pump and repair. |
| Pump runs, but output is low. | Inlet voltage too low. | Increase voltage. |
| | Faulty inlet (25, 26, 27) or discharge check valve (18, 19, 20). | Replace faulty components. |
| Weepage from housing cover 30. | Cup seal (16) or O-Ring (11) wore out. | Check the seals and replace if necessary. |
| Pump becomes noisy. | No crank case oil. | Add crank case oil. Remove Pipe Plug (38) from Pump Housing (39). Oil level should be at the bottom of the Pipe Plug opening. Add 10W30 motor oil until the crankcase is full. |
| | Worn wrist pin bushing 13. | Check the bushings and replace if necessary. |

FlowMaster™ Electric Pump

LINCOLN
INDUSTRIAL®

Lincoln Industrial
One Lincoln Way
St. Louis, MO 63120-1578
(+1) 314 679 4200
www.lincolnindustrial.com

Lincoln GmbH
69190 Walldorf
Heinrich-Hertz Strasse 2-8
(+49) 6227 33-0

Lincoln Industrial
25 International Business Park
#01-68 German Centre
Singapore 609916
(+65) 562-7960