FLOW COMPENSATOR KIT

FOR MODELS 1735 AND 1737 WITH PILE DRIVER PUMPS



Models 84142, 83812


MAXIMUM RECOMMENDED OPERATING PRESSURE 3000 PSI

The 83812 Flow Compensator should always be mounted in a vertical position with the 3/8" NPTF valve facing downwards. The 1-1/4" NPTF inlet and outlet ports may be used directly in line with material flow or with one side plugged and the other side connected to a pipe tee in the material supply line. The valve outlet or dump should be connected to follower on pressure primer models, or to a hole in the cover of models using a drum cover, to relieve pressure or recirculate the material.

IMPORTANT - Never remove the end plug or cylinder from compensator before shutting off pump and relieving material pressure.

TO CLEAN AND RESTORE AIR CHAMBER IN COMPENSATOR.

- 1 Shut off air supply to pump.
- 2 Turn handle to "down" position to relieve material pressure.
- 3 Remove end plug from cylinder and cylinder from valve body. Clean thoroughly.
- 4 Insert O-rings and replace if worn or damaged. Re-assemble end plug to cylinder and cylinder into valve body. Tighten securely.




LINCOLN ST. LOUIS
4010 GOODFELLOW BLVD. • ST. LOUIS, MO 63120 • (314) 383-5900



SECTION - K4

83812 FLOW COMPENSATOR



SERVICE PARTS

PART	DESCRIPTION	PART	DESCRIPTION	PART	DESCRIPTION
12896 14503 14504 14505 34353 34490 51040 61542	Adapter bushing Body Plug Retainer O-ring O-ring Nut Cylinder	66220 66499-6 66499-9 66499-14 66499-18 66499-20 66499-22	Washer Stem bushing nut Ball Thrust washer Stem Stem seal Teflon seat Back-up ring	66842 67389 67435 67436 72A020 361048	Adapter union Nipple Pipe plug Tee Hose Handle

RETAIN THIS INFORMATION FOR FUTURE REFERENCE

When ordering replacement parts, list: Part Number, Description, Model Number, and Series Letter.

LINCOLN ST. LOUIS provides a Distributor Network that stocks equipment and replacement parts.

A list of Authorized Service Departments will be furnished upon request.