## MCLP PUMP

**ANGLE DRIVE** 



# 


## **DESCRIPTION**

MCLP Pumps are plunger-type pumps, the plunger being actuated by a roller tappet assembly which is operated by the rotation of a cam.

Available with one or two adjustable pump heads, having either a 7mm or 11mm piston, and with single or double lobe cams. Dual head pumps can deliver a different oil from each pump head if required and the pump output can be regulated. An anchor cross, containing a purge port, rupture indicator, and outlet connection is supplied with each pump head.

## MODEL IDENTIFICATION

130400 Series - L.H. Right Angle Drive, Short Drive Shaft.
130450 Series - R.H. Right Angle Drive, Short Drive Shaft.
130500 Series - L.H. Right Angle Drive, Long Drive Shaft.
130550 Series - R.H. Right Angle Drive, Long Drive Shaft.



#### CODE LETTER IDENTIFICATION

The Drive Ratio for the MCLP Pumps will be specified by the first letter following the 130000 number:

Code	A	В	С	D	E	F	G	Н
Ratio	1:1	2:1	2.78:1	4:1	5.6:1	7.7:1	8:1	11.1:1
Code	J	K	L	M	N	P	R	S
Ratio	15.5:1	21.5:1	1:2	1:2.78	1:4	1:5.6	1.7.7	1:8

The output pressure of the 7mm & 11mm MCLP Pump Head is limited with some of the above ratios. For a complete explanation, contact factory.

The second and third letters following the 130000 number represent Pump Stations #1 and #2 respectively:

CODE	CAM	PUMPS*
A	15036 (single lobe)	130305 (w/7mm plunger)
В	16358 (double lobe)	130305 (w/7mm plunger)
C	15036 (single lobe)	130306 (w/11mm plunger)
D	16358 (double lobe)	130306 (w/11mm plunger)
**E	15036 (single lobe)	None
**F	16358 (double lobe)	None
***O	None	None

- \*Refer to Section M1, Page 10 Series for all pumps.
- \*\*Pump stations designated by E and F include mounting screws. Pump or pump station cover not included.
- \*\*\*Pump stations designated by O; cam, pump and roller tappet assembly are replaced by spacer and pump station cover.

## INSTALLATION


Mount the MCLP Pump to a rigid support or frame adjacent to the engine drive shaft or electric motor shaft. Carefully align the pump to the drive shaft. Fill the gear box to the half-way mark of the sight glass with Conoco SAE 80W-90 gear oil or equivalent before running the pump. The pump unit and the lubrication system should be purged of any entrapped air to ensure reliable oil delivery.

### **BLEEDING MCLP PUMP UNIT**

- 1) Connect filter primer to MCLP Pump inlet.
- 2) Loosen the pipe plug in the pump head and allow the oil to flow freely from the pipe plug until air bubbles no longer appear in the oil.
- 3) Set the MCLP Pump head to maximum output.
- 4) Loosen the outlet connection on the anchor cross and allow the pump to run until air bubbles no longer appear at the outlet. Tighten the outlet connection and turn off the pump.



SECTION -M20
PAGE - 3D



		Code						
		3	4	8	9	10	11	†† <b>42</b>
	1:1	15206	15322	15445	15445			66652
1	2:1	15206	15322	15475	15439			66652
1	2.78:1	15206	15322	15374	15390			66652
1	4:1	15206	15322	15445	15439	92875	92890	66652
I	5.6:1	15206	15322	15445	15439	92876	92880	66652
I	7.7:1	15206	15322	15445	15390	92862	92880	66652
	8:1	15206	15322	15475	15439	92875	92875	66652
Ratio	11.1:1	15206	15322	15374	15439	92875	92876	66652
Matto	15.5:1	15206	15322	15374	15439	92876	92862	66652
	21.5:1	15206	15322	15374	15390	92862	92862	66652
	1:2	16340	15955	15439	15475			15474
	1:2.78	16340	15955	15390	15374			15474
ł	1:4	16340	15955	15439	15445	92890	92875	15474
	1:5.6	16340	15955	15439	15445	92880	92876	15474
	1:7.7	16340	15955	15390	15445	92880	92862	15474
	1:8	16340	15955	15439	15475	92875	92875	15474

†† 15474 1/8" Wide Key 66652 3/16" Wide Key

## **SERVICE PARTS**

CODE	PART	QUAN.	DESCRIPTION	CODE	PART	QUAN.	DESCRIPTION	
1	5000	1	Lube fitting	31	48564	4	Washer	
2	*	As req'd	Cam	32	48582	†	Shim	
3	**	1	Drive shaft (short)	33	50521	4	Screw	
4	**	1	Drive shaft (long)	34	50522	As req'd	Set screw	
5	15367	2	Spacer	35	<b>505</b> 5	2	Set screw	
6	15368	2	Spacer	36	50792	As req'd	Screw	
7	15369	2	Tappet alignment screw	37	50833	22	Screw	
8	**	1	Spur gear - plain	38	50849	As req'd	Screw	
9	**	1	Spur gear - plain	39	51026	4	Nut	
10	**	1	Spur gear - cluster	40	66186	26	Lockwasher	
11	**	1	Spur gear - cluster	41	66220	4	Lockwasher	
12	15438	As req'd	Spacer	42	**	1	Key	
13	15474	1	Key	43	67359	1	Pipe plug	
14	15476	1	Drive shaft	44	68220	As req'd	#3 Woodruff key	
15	15836	2	Miter gear	45	68436	4	Lockwasher	
16	16357	1	Camshaft	46	68645	4	Pipe plug	
17	16376	1	Spacer	47	69853	As req'd	Oil seal	
18	31163	2	Gasket	48	69973-1	3	#5 Woodruff key	
19	33131	2	Pump gasket	49	69985	2	View gauge	
20	33132	1	Top cover gasket	50	69986	5	Bearing	
21	33133	2	End plate gasket	51	69987	5	Retaining ring	
22	34634	1	O-ring	52	69988	5	Retaining ring	
23	34674	1	O-ring	53	70075	1	Thrust bearing	
24	40719	1	Blank end plate	54	70150	1	Bearing	
25	40721	1	Gear case housing	55	70151	1	Roller bearing	
26	40771	1	Drive shaft support housing	56	92863	1	Gear case cover assembly	
27	40774	1	Drive shaft support housing	57	93324	1	Drive end plate assembly	
28	40801	1	Drive housing	58	***	As req'd	Pump head assembly	
29	45989	As req'd	Pump station cover	59	880124	As req'd	Roller tappet assembly	
30	48558	1	Washer					

- \* 15036 Single Lobe Cam or 16358 Double Lobe Cam as designated.
- \*\* See chart above
- \*\*\* 7mm pump or 11mm pump as required. See Code Chart on front page.
  - † Use as required to obtain a maximum of .015 vertical movement of drive shaft.

## - RETAIN THIS INFORMATION FOR FUTURE REFERENCE -

When ordering replacement parts, list: Part Number, Description, Model Number, and Series Letter. LINCOLN ST. LOUIS provides a Distributor Network that stocks equipment and replacement parts.