# TEFLON KIT




# Model 83964

TO CONVERT PACKING GLAND

The Teflon Gland and Piston Packing Kit should be used when dispensing materials which are not compatible with the standard Polyurethane and Buna-N Packings.

## STANDARD PUMP GLAND

Remove the following parts; 92115, 69280, 34427, 34425, 34529.



SEE REVERSE SIDE FOR "TEFLON" PACKING KIT INSTALLATION PROCEDURE



#### INSTALLATION PROCEDURE

Invert 38140 "U" Cup Packing and force over Piston Rod. (This is done to "size" the hole in the packing.) Remove 38140 "U" Cup Packing from Piston Rod.

Assemble all parts included in the Gland Assembly. Do not tighten the 14747 Spreader Nut at this time.


Insert Piston Rod up through Gland Assembly and tighten the 14747 Spreader Nut.

Screw Gland Assembly into Pump Outlet Casting.

Insert 34534 "O" Ring into Check, and 34535 "O" Ring into Check Bushing, and slip onto Piston Rod.

Re-Assemble pump tube to complete installation of "Teflon" Packing Kit.

NOTE: 34534 "O" Ring and 14647 Check must be fully depressed into outlet body before assembling lower section parts.



### --- RETAIN THIS INFORMATION FOR FUTURE REFERENCE ----

When ordering replacement parts, list: Part Number, Description, Model Number, and Series Letter.

LINCOLN ST. LOUIS provides a Distributor Network that stocks equipment and replacement parts. A list of Authorized Service Departments will be furnished upon request.