



Part	Qty.	Description
1	2	Signal valve cap
2	4	Socket head cap screw
3	2	Back-up ring

NOTE: Back-up ring is used only on Air Brakes® that have an "S" stamped on the side of the body.