

1. Security code is 1, 2, 3, 4.
2. Power switch is in AC position.
3. Controller has been configured as follows:

Centro-Matic Controller?.....YES  
Using One Pump?.....YES  
Using Multiple Zones?.....NO  
Timing between Cycles?.....YES  
Time between Cycles .....30 minutes  
Maximum Pump On Time .....2 minutes  
Is Secondary Timer Needed?.....NO  
Purge Spray Head W/Air after Lube?.....NO  
Stop Lube System when in Alarm?.....NO  
Alarm Contact Closes on Fault?.....YES  
Will You Use Low Level Alarm?.....NO  
Do You Need a PreLube Cycle?.....NO  
Allow Manual Lube at Keypad?.....YES  
Maximum Pressure Ends Lube Cycle?.....YES  
Pressure Switch? No  
Transducer? Yes.....YES  
Transducer Offset Voltage? .....1.0  
Maximum Transducer PSI Rating?.....4000  
Maximum System PSI?.....2500  
Does System uses SL-1 Injectors?.....YES  
Vent Pressure set at 600psi OK?.....YES  
One Cycle per Lube Event?.....YES  
Are You Using Sensors?.....NO

---

**RETAIN THIS INFORMATION FOR FUTURE REFERENCE**

When ordering replacement parts, list: Part Number, Description, Model Number and Series Letter.  
LINCOLN provides a Distributor Network that stocks equipment and replacement parts.