



\* Refer to separate instructions:  
815 Air Coupler Section G9 Page 2 Series  
84933 Basic Pump Section A6, Page 38 Series

**SERVICE PARTS**

Part	Qty.	Description	Part	Qty.	Description
815	1	Air Coupler	51055	1	Nut
5698	1	Vent Fitting	64412	2	Tie Rod Bracket
11348	1	Adapter	66191	2	Wing Nut
11373	2	Tie Rod	66192	2	Eye Bolt
11659	1	Air Coupler Nipple	66193	2	Lockwasher
31038	4	Copper Gasket	68531	1	Eye Bolt
31184	1	Gasket	72060	1	Air Hose
33116	1	Gasket	73060	1	Lubricant Hose
34691	1	Gasket	83115	1	Drum Cover & Tie Rod Assembly
45870	1	Drum Cover Assen	84319	1	Pump Bushing Assembly
50006	4	Screw	84933	1	Basic Pump Assembly
50022	4	Screw	85935	1	Airmotor Cover
50060	4	Bolt	85755	1	Tube
51007	4	Nut	236975	1	Adapter
51010	4	Nut	241584	1	Outlet Connection
51017	2	Nut	360640	1	Cover Plate