





MODEL 84191		
REPAIR PART LIST		
REQ'D	PART NO.	DESCRIPTION
1	50146	5/16"-18 x 1-1/2" Hex Head Machine Screw
1	50147	5/16"-18 x 5/8" Hex Head Machine Screw
1	51057	Nut
4	66060	Caster
1	92708	Caster Strap Assembly

MODEL 84192		
REPAIR PART LIST		
REQ'D	PART NO.	DESCRIPTION
1	50146	5/16"-18 x 1-1/2" Hex Head Machine Screw
1	51057	Nut
4	66060	Caster
1	92709	Caster Strap Assembly

RETAIN THIS INFORMATION FOR FUTURE REFERENCE

When ordering replacement parts, list: Part Number, Description, Model Number and Series Letter.

LINCOLN provides a Distributor Network that stocks equipment and replacement parts.
A list of Authorized Service Departments will be furnished upon request.