



SERVICE PARTS

Part	Qty.	Description
10472	3	Toggle pin
11630	1	Expeller tube adapter
13893	1	Connecting rod
34121	1	Piston packing
34122	1	Check disc packing
34166	1	O-ring
40067	1	Handle
40509	1	Cylinder head
45658	1	Packing retainer
45659	2	Piston
45744	1	Toggle
48039	2	Washer
48245	1	Piston check disc
55368	1	Piston spring
61409	1	Nozzle tube
62130	1	Air expeller tube
66031	3	Cotter pin
90058	1	Foot valve assembly