


<b>* REFER TO SEPARATE INSTRUCTIONS</b>	
81383	Basic Pump
84363	Meter Ass'y



## SERVICE PARTS

Part	Qty.	Description	Part	Qty.	Description
10711	1	Nozzle check	57017	1	Spring
10712	1	Nozzle tip	62054	1	Nozzle tube
11123	4	Screw	66060	4	Caster
11197	1	Adapter	74560	1	Hose
12134	1	Elbow	80489	1	Hose & nozzle assembly
45880	1	Truck plate assembly	80599	1	Nozzle assembly
46007	1	Drum cover	80895	1	Truck assembly
48238	4	Washer	81383	1	Bare pump assembly
48311	1	Reinforcing washer	84363	1	Meter assembly
50016	4	Screw	360266	4	Clamp
50060	3	Screw			

**RETAIN THIS INFORMATION FOR FUTURE REFERENCE**

When ordering replacement parts, list: Part Number, Description, Model Number, and Series Letter.

LINCOLN provides a Distributor Network that stocks equipment and replacement parts.