

84101 - replander & Model No. 84501 PROGRAM TIMER

U.L. AND C.S.A. LISTED

Series "B"



# WARNING

SHOCK HAZARD. **TURN** POWER OFF BEFORE SERVIC-ING.

## SPECIFICATIONS

Electrical ...... 120/230 VAC 50/60 Hz

Switch Ampacity ...... 5 amps, 120 VAC

1.5 amps, 230 VAC

Temperature Range ...... 0°F to 131°F

(-18°C to 55°C)

Enclosure ...... NEMA 1

Prelube On Time ...... 40 seconds Memory Time ...... 3 hours




FIGURE 1

#### **OPERATION**

Model 84501 Program Timer is used to program the lubrication cycle frequency of single stroke lubricant pumps. Lube cycles will be determined by the setting on the On/Off Time Selector rocker switches. "On/Off" times should

be selected to meet system requirements (see Time Selection). During the "On" time the solenoid valve or load device (not part of timer) connected to terminals 7 & 8 is energized (amber L.E.D. will light).

### **FEATURES**

### Memory/Prelube

Timer has the capability of retaining memory for 3 hours during machine shut down or power failure. Timing is suspended during power interruptions. This feature eliminates over lubrication due to prelube (prelube occurs when power is applied to timer) when machine is frequently started and stopped.

Using two programmable jumper pins four options are available with the memory and prelube feature.

### Jumper Pin A

Vertical Position - Memory On Horizontal Position - Memory Off

#### Jumper Pin B

Vertical Position - Prelube On Horizontal Position - Prelube Off

### Option 1

Memory On - Jumper Pin A/Vertical Position.

Prelube On - Jumper Pin B/Vertical Position.

Prelube only occurs if power has been off longer than 3 hours.

#### Option 2

Memory On - Jumper Pin A/Vertical Position.

Prelube Off - Jumper Pin B/Horizontal Position

When timer has been off longer than three hours the next lube cycle will occur after the full amount of Off Time has timed out.

## Option 3

Memory Off - Jumper Pin A/Horizontal Position.

Prelube On - Jumper Pin B/Vertical

When power is applied a prelube cycle is initiated.

## Option 4

Memory Off - Jumper Pin A/Horizontal Position.


Prelube Off - Jumper Pin B/Horizontal Position.

When power is applied the first lube cycle will occur when the full amount of Off Time has timed out.



One Lincoln Way St. Louis, Missouri 63120-1578 (314) 679-4200 Customer Service, (314) 679-4300

Copyright 1988 Printed in U.S.A. Section - C8



# **SERVICE PARTS**


Part Qty.		Description				
239425	1	Jumper shunt (strip of ten)				
*322033	2	Integrated circuit				
*322048	1	Integrated circuit				
*322061	1	Integrated circuit				
*322055	1	Integrated circuit				
*322063	1	Integrated circuit				
328529	1	Amber L.E.D. with fastener				
328530	1	Green L.E.D. with fastener				
239443	1	Circuit board assembly				

\* Included in 239448 Repair Kit.
Repair kit also includes 237001 IC Insertion Tool & 237067 Extractor Tool.

## IMPORTANT:

Servicing of this unit should be done only by a qualified electronics technician or engineer trained in handling solid state equipment.

Use proper tools when removing or replacing integrated circuits on the 239443 Circuit Board.



# TIME SELECTION CHART

ON TIME	OFF TIME	CLOSE SW #	SW 11	SW 12	ON TIME	OFF TIME	CLOSE SW #	SW 11	SW 12
10 SEC	20 SEC	1	CLOSED	CLOSED	1 MIN	2 MIN	1	OPEN	CLOSED
10 SEC	40 SEC	2	CLOSED	CLOSED	1 MIN	4 MIN	2	OPEN	CLOSED
10 SEC	1 MIN 20 SEC	3	CLOSED	CLOSED	1 MIN	8 MIN	3	OPEN	CLOSED
10 SEC	2 MIN 40 SEC	4	CLOSED	CLOSED	1 MIN	16 MIN	4	OPEN	CLOSED
10 SEC	5 MIN 15 SEC	5	CLOSED	CLOSED	1 MIN	32 MIN	5	OPEN	CLOSED
10 SEC	10 MIN 30 SEC	6	CLOSED	CLOSED	1 MIN	1 HR 4 MIN	6	OPEN	CLOSED
10 SEC	21 MIN	7	CLOSED	CLOSED	1 MIN	2 HR 9 MIN	7	OPEN	CLOSED
10 SEC	42 MIN	8	CLOSED	CLOSED	1 MIN	4 HR 18 MIN	8	OPEN	CLOSED
10 SEC	1 HR 24 MIN	9	CLOSED	CLOSED	1 MIN	8 HR 35 MIN	9	OPEN	CLOSED
10 SEC	2 HR 48 MIN	10	CLOSED	CLOSED	1 MIN	17 HR 9 MIN	10	OPEN	CLOSED
34 SEC	1 MIN 8 SEC	1	CLOSED	OPEN	1 MIN 24 SEC	2 MIN 48 SEC	1	OPEN	OPEN
34 SEC	2 MIN 16 SEC	2	CLOSED	OPEN	1 MIN 24 SEC	5 MIN 36 SEC	2	OPEN	OPEN
34 SEC	4 MIN 30 SEC	3	CLOSED	OPEN	1 MIN 24 SEC	11 MIN 12 SEC	3	OPEN	OPEN
34 SEC	9 MIN	4	CLOSED	OPEN	1 MIN 24 SEC	22 MIN 30 SEC	4	OPEN	OPEN
34 SEC	18 MIN	5	CLOSED	OPEN	1 MIN 24 SEC	45 MIN	5	OPEN	OPEN
34 SEC	36 MIN	6	CLOSED	OPEN	1 MIN 24 SEC	1 HR 30 MIN	6	OPEN	OPEN
34 SEC	1 HR 12 MIN	7	CLOSED	OPEN	1 MIN 24 SEC	3 HR	7	OPEN	OPEN
34 SEC	2 HR 24 MIN	8	CLOSED	OPEN	1 MIN 24 SEC	6 HR	8	OPEN	OPEN
34 SEC	4 HR 48 MIN	9	CLOSED	OPEN	1 MIN 24 SEC	12 HR	9	OPEN	OPEN
34 SEC	9 HR 35 MIN	10	CLOSED	OPEN	1 MIN 24 SEC	24 HR	10	OPEN	OPEN

## TIME SELECTION (refer to Fig. 1)

Determine "On" time (time solenoid valve or load device is energized) and "Off" time (time between lube cycles) for system requirements. Select appropriate "On" time from Time Selection Chart and set rocker switches #11 and #12 accordingly. Select "Off" time corresponding to "On" time and close the switch from #1 and #10 indicated in chart. **Only one** switch from #1 to #10 should be closed.

## MANUAL LUBE (refer to Fig. 1)

Push the manual lube switch (inside enclosure) or optional remote manual lube switch and hold to initiate a lube cycle. Solenoid will remain energized as long as manual lube switch is actuated.

# **LED STATUS**

Green L.E.D. indicates Power On. Amber L.E.D. indicates Pump On.

# SURGE SUPPRESSOR/ SHIELDED WIRE

In some cases it may be necessary to use a surge suppressor when an inductive device is being controlled.

It is recommended that shielded wire be used on input/output lines to reduce problems with electrical noise.

### WIRE CONNECTIONS

#### Power Source - Terminals 1 & 2


120 VAC, 50 or 60 Hz, connect jumper wire between Terminal 3 & 4 and between Terminals 5 & 6.

230 VAC, 50 or 60 Hz, connect jumper wire between Terminal 4 & 5.

Solenoid Valve or Load Device - Terminals 7 & 8. Max. load 120/240 VAC at 360 Volt-amps.

Remote Manual Lube Pushbutton Switch (Momentary N.O.) - Terminals 1 & 7.

# WIRING DIAGRAMS



NOTE: Numbers in circles represent corresponding numbers on terminal strip inside timer enclosure.

 	······································	 	<del></del>	 <del></del>

LINCOLN provides a Distributor Network that stocks equipment and replacement parts.