





HOSE REELS
(SPRING ACTUATED)

Models **83408, 83409, 83410, 83411, 102698**

Series B




*B15 AIR COUPLER — REFER TO SERVICE MANUAL SECTION G1 PAGE 1 SERIES


LINCOLN

LINCOLN, One Lincoln Way
St Louis, Missouri 63120-1578
(314) 679-4200 Customer Service, (314) 679-4300

SECTION - **E35**
PAGE - **27E**



**MODEL 83408
 BARE HOSE REEL**



REPAIR PARTS LIST

PART NO	DESCRIPTION	PART NO	DESCRIPTION
815	Air Coupler	66051	Lockwasher
14012	Swivel Block	66186	Lockwasher
14013	Stud	66220	Lockwasher
14014	Latch	66246	Lockwasher
14935	Inlet Stud	66316	Retaining Ring
20011	Bushing	66842	Adapter Union
34245	O-Ring	67358	Elbow
45897	Clip	68340	Instruction Decal
48436	Washer	68559	Retaining Ring
48506	Washer	72012	Hose Assembly
50044	3/8"-16 Hex Hd Cap Screw	72240	Hose Assembly
50073	= 10-32 Hex Hd Machine Screw	72A300	Hose Assembly
50302-1	1/4"-20 Rd Hd Screw	72420	Hose Assembly
50310-1	1/4"-20 Rd Hd Screw	83408	Base Hose Reel
50781	5/16"-18 Allen Screw	83620	Swivel Assembly
51005	3/8"-16 Hex Nut	83515	Ball Stop Assembly
51009	1/4"-28 Hex Nut	91988	Arbor Assembly
51010	1/4"-20 Hex Nut	91989	Base Assembly
51022	5/16"-18 Hex Nut	91991	Roller Outlet Assembly
51043	= 10-32 Hex Nut	92069	Sheave Assembly
57110	Power Spring Assembly	92072	Ball Stop
57111	Latch Spring	92076	Sheave Assembly
65099	Serial Plate	360310	Roller Support Angle

RETAIN THIS INFORMATION FOR FUTURE REFERENCE

When ordering replacement parts, list: Part Number, Description, Model Number, and Series Letter.

LINCOLN ST. LOUIS provides a Distributor Network that stocks equipment and replacement parts.
A list of Authorized Service Departments will be furnished upon request.