



SERVICE PARTS

Part	Qty.	Description
15102	1	Coupling Nut
16369	1	Actuator Pin
16370	1	Adaptor
16371	1	Actuator lever
16485	1	Plug
48052	1	Washer
50421	4	Screw
50556	1	Set Screw
68932	3	Screw
69868	1	Counter

To Assemble Cycle Counter To Divider Valve w/Cycle Indicator

NOTE: CYCLE INDICATOR PLUG MUST BE REMOVED FROM DIVIDER VALVE IN ORDER TO COUPLE TO COUNTER WITH 15102 COUPLING NUT.

* Applies to Series "A" valves only

© Indicates Change

