TEFLON KIT 83616 PUMP TUBE ASSEMBLY "**A" &** "B" SERIES




Model 83966

The Teflon Packing Kit should be used when dispensing materials which are not compatible with the standard Polyurethane and Buna-N Packings.


STANDARD PUMP GLAND

Remove the following parts; 31114, 34415, 34426, 34517, 69277, 92289.



STANDARD PUMP GLAND

Remove the following parts; 31114, 34415, 34426, 34517, 34529, 69277, 92289.



A` 7 🔺 PAGE

INSTALLATION PROCEDURE

Invert 38140 U-Cup Packing and force over Piston Rod. (This is done to "size" the packing bore.) Remove 38140 U-Cup Packing from Piston Rod.

Assemble all parts included in the Gland Assembly. Do not tighten the 14747 Spreader Nut at this time.

Insert Piston Rod up through the Gland Assembly and tighten the 14747 Spreader Nut.

Screw Gland Assembly into Pump Outlet Casting.

Series "A"

Insert two 34537 O-Rings into Upper Check Bushing and install in pump.

Series "B"

Install one 34534 "O" Ring on 14647 Check and install in pump.

Series "B"

Insert one 34537 "O" Ring into Check Bushing and install in pump.

Insert 34536 "O" Ring into Foot Valve Check and install on Priming Rod.

Complete assembly of pump tube.

NOTE: 34534 "O" Ring and 14647 Check must be fully depressed into outlet body before assembling lower section parts.

