



## **ASSEMBLY INSTRUCTIONS**

- 1. Slide bottom pump cover up over pump tube and fasten with (4) screws provided. Note: if pump is used with drum cover, slide drum cover up over pump tube and mount flush against the bottom pump cover and fasten using (4) screws provided.
- 2. Assemble one of the two outlet adapters provided through the bottom pump cover and into the pump. The other adapter can be discarded.
- 3. Assemble top pump cover over the pump to fit onto bottom pump cover and fasten using the knurled lock nut provided.
- 4. Assemble the inlet adapter through the top pump cover and into the pump.



One Lincoln Way St Louis, Missouri 63120-1578 (314) 679-4200 Customer Service, (314) 679-4300

Copyright 1987 Printed in USA SECTION - K5

PAGE - 3